

MICROSAR RTE

Technical Reference

Version 4.8.0

Authors	Bernd Sigle, Martin Schlodder, Sascha Sommer, Stephanie Schaaf, Katharina Benkert, Cornelius Reuss
Status	Released



Document Information

History

Author	Date	Version	Remarks
Bernd Sigle	2005-11-14	2.0.0	Document completely reworked and adapted to AUTOSAR RTE
Bernd Sigle	2006-04-20	2.0.1	API description for Rte_IRead / Rte_IWrite added, description of used OS/COM services added
Bernd Sigle	2006-07-11	2.0.2	API description for Rte_Receive / Rte_Send added; Adaptation to RTE SWS 1.0.0 Final
Martin Schlodder	2006-11-02	2.0.3	Separation of RTE and target package
Martin Schlodder	2006-11-15	2.0.4	Client/Server communication
Martin Schlodder	2006-12-21	2.0.5	Serialized client/server communication
Martin Schlodder	2007-01-17	2.0.6	Array data types
Martin Schlodder	2007-02-14	2.0.7	Added exclusive areas, removed description of TargetPackages
Bernd Sigle	2007-02-19	2.0.8	Added transmission acknowledgement handling and minor rework of the document
Bernd Sigle	2007-04-25	2.0.9	Added Rte_IStatus
Martin Schlodder	2007-04-27	2.0.10	Added IRV and Const/Enum
Martin Schlodder Bernd Sigle	2007-05-01	2.1.0	Completed documentation for Version 2.2
Bernd Sigle	2007-07-27	2.1.1	Added Rte_InitMemory, Rte_IWriteRef Runnable. Added description of runnable activation offset und updated picture of MICROSAR architecture.
Martin Schlodder	2007-08-03	2.1.2	Added description of template update.
Martin Schlodder Bernd Sigle	2007-11-16	2.1.3	Added warning regarding IWrite / IrvIWrite. Added API descriptions of VFB trace hooks. Updated data type info for nested types.
Martin Schlodder Bernd Sigle	2008-02-06	2.1.4	Updated descriptions on template merging and task mapping. Added description of Rte_Pim, Rte_CData, Rte_Calprm and Rte_Result. Added support of string data type. Updated command line argument description. Added NvRAM mapping description. Added chapter about compiler abstraction and memory mapping.
Hannes Futter	2008-03-11	2.1.5	Additional command line switches to support direct generation on xml and dcf files.
Bernd Sigle	2008-03-26	2.2.0	Updated description of NV Memory Mapping and Chapter about limitations added. Chapter about compiler and memory abstraction updated. Support for AUTOSAR Release 3.0 added.



Bernd Sigle	2008-04-16	2.3.0	Added description about A2L file generation and updated command line options and example calls to cover also the AUTOSAR XML input files.
Bernd Sigle	2008-07-16	2.4.0	Removed limitations for multiple instantiation and compatibility mode support.
Bernd Sigle	2008-08-13	2.5.0	Added description of indirect APIs Rte_Port, Rte_Ports and Rte_NPorts. Added description of platform dependent resource calculation.
Bernd Sigle	2008-10-23	2.6.0	Added description of memory protection support.
Bernd Sigle	2009-01-23	2.7.0	Added description of mode management APIs Rte_Mode and Rte_Switch and updated description of Rte_Feedback. Added description of Rte_Invalidate and Rte_Ilnvalidate and added new Com APIs. Added additional runnable trigger events and removed section for runnables without trigger, which is no longer supported. Deviation for [rte_sws_2648] added. Usage of new document template
Bernd Sigle	2009-03-26	2.8.0	Removed limitations for unconnected ports and for data type generation.
Sascha Sommer Bernd Sigle	2009-08-11	2.9.0	Added description about usage of basic / extended task Added description of command line parameter -v
Sascha Sommer Bernd Sigle	2009-10-22	2.10.0	Added a warning for VFB trace hooks that prevent macro optimizations Explained that the Activation task attribute has to be set for basic tasks Init-Runnables no longer need to have a special suffix Explained the new periodic trigger implementation dialog. Server runnables with CanBelnvokedConcurrently set to false do not need to be mapped to tasks when the calling clients cannot interrupt each other Resource Usage is now listed in a HTML report Updated version of referenced documents and of supported AUTOSAR release. Updated examples with new workspace file extension. Added new defines for memory mapping.
Bernd Sigle	2010-04-09	2.11.0	Added description of user header file Rte_UserTypes.h Updated component history and interface functions to the OS. Added pictures of Rte Interfaces and Rte Include Structure. Updated picture of MICROSAR
			architecture. Rework of chapter structure.



Bernd Sigle Sascha Sommer	2010-05-26	2.12.0	Added new measurement chapter, added description of COM Rx Filter, macros for access of invalid value, initial value, lower and upper limit, added support of minimum start interval and second array passing variant. Support of AUTOSAR Release 3.1 (RTE SWS 2.2.0)
Bernd Sigle	2010-07-22	2.13.0	Added online calibration support. Removed limitation of missing transmission error detection
Bernd Sigle	2010-09-28	2.13.1	Added more detailed description of extended record data type compatibility rule
Bernd Sigle	2010-11-23	2.14.0	Removed obsolete command line parameters –bo, –bc and –bn.
Stephanie Schaaf Bernd Sigle Sascha Sommer	2011-07-25	2.15.0	Added general support of AUTOSAR Release 3.2.1 (RTE SWS 2.4.0). Added support of never received status. Added support of S/R update handling. Mentioned that –g c and –g i ignore service components when –m specifies an ECU project. Explained RTE usage with Non-Trusted BSW Added hint for FUNC_P2CONST() problems Explained measurement of COM signals
Stephanie Schaaf Bernd Sigle Sascha Sommer	2012-01-25	2.16.0	Enhanced command line interface (support for several generation modes in one command line call, optional command line parameter –m) Split of RTE into OS Application specific files Byte arrays no longer need to be mapped to signals groups Allow configuration of Schedule() calls in non-preemptive tasks
Bernd Sigle	2012-05-18	2.17.0	Corrected description how the Rte_IsUpdated API can be enabled
Bernd Sigle	2012-09-18	2.18.0	Added general support of AUTOSAR Release 3.2.2 (RTE SWS 2.5.0). Added support of non-queued N:1 S/R communication
Bernd Sigle	2012-08-28	3.90.0	AUTOSAR 4.0.3 support, DaVinci Configurator 5 support
Bernd Sigle	2012-12-11	4.0.0	Updated API descriptions concerning RTE_E_UNCONNECTED return code Added description of Rte_UserTypes.h file which is now also generated with the template mechanism
Stephanie Schaaf	2013-03-26	4.1.0	Added support of Rte_MemSeg.a2l file Added description of –o sub option for A2L file path
Bernd Sigle	2013-06-14	4.1.1	Added Multi-Core support (S/R communication) Added support of Inter-Runnable Variables with composite data types



Katharina Benkert Stephanie Schaaf Sascha Sommer Bernd Sigle	2013-10-30	4.2.0	Added support for arrays of dynamic data length (Rte_Send/Rte_Receive) Added support for parallel generation for multiple component types Multicore support Added support for SchM Contract Phase Generation Added support for Nv Block SWCs
Katharina Benkert Sascha Sommer Stephanie Schaaf	2014-02-06	4.3.0	Added support of VFB Trace Client Prefixes Optimized Multicore support without IOCs Memory Protection support for Multicore systems Inter-ECU sender/receiver communication, queued sender/receiver communication and mapped client/server calls are no longer limited to the BSW partition Added support of Development Error Reporting Added support of registering XCP Events in the XCP module configuration
Stephanie Schaaf Bernd Sigle	2014-06-17	4.4.0	Support for unconnected client ports for synchronous C/S communication Inter-Ecu C/S communication using SOME/IP Transformer Support for PR-Ports S/R Serialization using SOME/IP Transformer and E2E Transformer Support LdCom
Bernd Sigle	2014-08-13	4.4.1	Described decimal coding of the version defines and the return code of SchM_GetVersionInfo Added chapter about additional copyrights of FOSS
Bernd Sigle	2014-09-12	4.4.2	Minor format changes only
Bernd Sigle	2014-08-13	4.5.0	Support Postbuild-Selectable for variant data mappings and variant COM signals Support E2E Transformer for Inter-Ecu C/S communication Support tasks mappings where multiple runnable or schedulable entities using different cycle times or activation offsets are mapped to a single Basic Task. The realization uses OS Schedule Tables Support Rte_DRead API Enhanced support for PR-Ports Support ServerArgumentImplPolicy = use ArrayBaseType Explicit order of ModeDeclarationGroups



Bernd Sigle	2014-12-08	4.6.0	Support of PR Mode Ports Support of PR Nv Ports Support of bit field data types (CompuMethods with category BITFIELD_TEXTTABLE) Runtime optimized copying of large data Support for SW-ADDR-METHOD on RAM blocks of NvRAM SWCs
Bernd Sigle	2015-02-20	4.7.0	Support of background triggers Support of data prototype mappings Support of bit field text table mappings Support of union data types Support of UTF16 data type serialization in the SOME/IP transformer Runtime optimization in the generated RTE code by usage of optimized interrupt locking APIs of the MICROSAR OS Support of further E2E profiles for data transformation with the SOME/IP and E2E transformer Support of OS counters with tick durations smaller than 1µs
Bernd Sigle	2015-07-26	4.8.0	Support of COM based Transformer ComXf Support of different strategies for writing NV data in Nv Block SWCs Support of C/S Interfaces for Nv Block SWCs SWC Template generation provides user sections for documentation of runnable entities Wide character support in paths Improved counter selection for operating systems with multiple OS applications Support of optimized macro implementation for SchM_Enter and SchM_Exit Enhanced OS Spinlock support Enable optimizations in QM partitions

Table 1-1 History of the document



Reference Documents

No.	Title	Version
[1]	AUTOSAR_SWS_RTE.pdf	3.2.0
[2]	AUTOSAR_EXP_VFB.pdf	2.2.0
[3]	AUTOSAR_SWS_COM.pdf	4.2.0
[4]	AUTOSAR_SWS_OS.pdf	5.0.0
[5]	AUTOSAR_SWS_NVRAMManager.pdf	3.2.0
[6]	AUTOSAR_SWS_ECU_StateManager.pdf	3.0.0
[7]	AUTOSAR_SWS_StandardTypes.pdf	1.3.0
[8]	AUTOSAR_SWS_PlatformTypes.pdf	2.5.0
[9]	AUTOSAR_SWS_CompilerAbstraction.pdf	3.2.0
[10]	AUTOSAR_SWS_MemoryMapping.pdf	1.4.0
[11]	AUTOSAR_TPS_SoftwareComponentTemplate.pdf	4.2.0
[12]	AUTOSAR_TPS_SystemTemplate.pdf	4.2.0
[13]	AUTOSAR_TPS_ECUConfiguration.pdf	3.2.0
[14]	AUTOSAR_TR_Glossary.pdf	2.4.0
[15]	AUTOSAR_TPS_BSWModuleDescriptionTemplate.pdf	2.2.0
[16]	AUTOSAR_SWS_XCP.pdf	2.0.0
[17]	AUTOSAR_SWS_ DevelopmentErrorTracer.pdf	3.2.0
[18]	Vector DaVinci Configurator Online help	
[19]	Vector DaVinci Developer Online help	
[20]	AUTOSAR Calibration User Guide	1.0

Table 1-2 Reference documents

Scope of the Document

This document describes the MICROSAR RTE generator. It assumes that the reader is familiar with the AUTOSAR architecture, especially the software component (SWC) design methodology and the AUTOSAR RTE specification. It also assumes basic knowledge of some basic software (BSW) modules like AUTOSAR Os, Com, LdCom, NvM and EcuM. The description of those components is not part of this documentation. The related documents are listed in Table 1-2.

Technical Reference MICROSAR RTE





Please note

We have configured the programs in accordance with your specifications in the questionnaire. Whereas the programs do support other configurations than the one specified in your questionnaire, Vector's release of the programs delivered to your company is expressly restricted to the configuration you have specified in the questionnaire.



Contents

1 Component History				15		
2	Intro	duction		20		
	2.1	Archited	cture Overview	21		
3	Func	tional Des	scription	24		
	3.1	Feature	es	24		
		3.1.1	Deviations	26		
		3.1.2	Additions/ Extensions			
		3.1.3	Limitations	27		
	3.2	Initializa	ation	28		
	3.3	AUTOS	AR ECUs	28		
	3.4	AUTOS	AR Software Components	28		
	3.5	Runnab	ole Entities	28		
	3.6	Triggeri	ng of Runnable Entities	29		
		3.6.1	Time Triggered Runnables	29		
		3.6.2	Data Received Triggered Runnables	30		
		3.6.3	Data Reception Error Triggered Runnables	30		
		3.6.4	Data Send Completed Triggered Runnables	30		
		3.6.5	Mode Switch Triggered Runnables	30		
		3.6.6	Mode Switched Acknowledge Triggered Runnables	30		
		3.6.7	Operation Invocation Triggered Runnables	31		
		3.6.8	Asynchronous Server Call Return Triggered Runnables	31		
		3.6.9	Init Triggered Runnables	31		
		3.6.10	Background Triggered Runnables	31		
	3.7	Exclusiv	ve Areas	32		
		3.7.1	OS Interrupt Blocking	32		
		3.7.2	All Interrupt Blocking	32		
		3.7.3	OS Resource	33		
		3.7.4	Cooperative Runnable Placement	33		
	3.8	Error Ha	andling	34		
		3.8.1	Development Error Reporting	34		
4	RTE (Generatio	n and Integration	36		
	4.1	Scope of	of Delivery	36		
	4.2	RTE Ge	eneration	37		
		4.2.1	Command Line Options	37		
		4.2.2	RTE Generator Command Line Options	37		
		4.2.3	Generation Path	39		



4.3	MICRO	SAR RTE generation modes	39
	4.3.1	RTE Generation Phase	39
	4.3.2	RTE Contract Phase Generation	41
	4.3.3	Template Code Generation for Application Software Components .	43
	4.3.4	VFB Trace Hook Template Code Generation	44
4.4	Include	Structure	45
	4.4.1	RTE Include Structure	45
	4.4.2	SWC Include Structure	46
	4.4.3	BSW Include Structure	47
4.5	Compile	er Abstraction and Memory Mapping	48
	4.5.1	Memory Sections for Calibration Parameters and Per-Instance Memory	50
	4.5.2	Memory Sections for Software Components	51
	4.5.3	Compiler Abstraction Symbols for Software Components and RTE	52
4.6	Memor	y Protection Support	53
	4.6.1	Partitioning of SWCs	53
	4.6.2	OS Applications	53
	4.6.3	Partitioning Architecture	54
	4.6.4	Conceptual Aspects	57
	4.6.5	Memory Protection Integration Hints	58
4.7	Multico	re support	59
	4.7.1	Partitioning of SWCs	59
	4.7.2	BSW in Multicore Systems	
	4.7.3	IOC Usage	
4.8	BSW A	ccess in Partitioned systems	
	4.8.1	Inter-ECU Communication	
	4.8.2	Client Server communication	61
ΔΡΙ Γ)escriptio	n	62
5.1	-	/pe Definition	
	5.1.1	Invalid Value	
	5.1.2	Upper and Lower Limit	
	5.1.3	Initial Value	
5.2	API Err	or Status	63
5.3	Runnak	ole Entities	64
	5.3.1	<runnableentity></runnableentity>	64
5.4	SWC E	xclusive Areas	66
	5.4.1	Rte_Enter	66
	5.4.2	Rte_Exit	67
5.5	BSW E	xclusive Areas	68
	551	SchM Enter	68

5



	5.5.2	SchM_Exit	69
5.6	Sender-l	Receiver Communication	70
	5.6.1	Rte_Read	70
	5.6.2	Rte_DRead	71
	5.6.3	Rte_Write	72
	5.6.4	Rte_Receive	73
	5.6.5	Rte_Send	74
	5.6.6	Rte_IRead	75
	5.6.7	Rte_IWrite	76
	5.6.8	Rte_IWriteRef	77
	5.6.9	Rte_IStatus	78
	5.6.10	Rte_Feedback	79
	5.6.11	Rte_IsUpdated	80
5.7	Data Ele	ement Invalidation	81
	5.7.1	Rte_Invalidate	81
	5.7.2	Rte_IInvalidate	82
5.8	Mode Ma	lanagement	83
	5.8.1	Rte_Switch	83
	5.8.2	Rte_Mode	84
	5.8.3	Enhanced Rte_Mode	85
	5.8.4	Rte_SwitchAck	86
5.9	Inter-Ru	nnable Variables	87
	5.9.1	Rte_IrvRead	87
	5.9.2	Rte_IrvWrite	88
	5.9.3	Rte_IrvIRead	89
	5.9.4	Rte_IrvIWrite	90
5.10	Per-Insta	ance Memory	91
	5.10.1	Rte_Pim	91
5.11	Calibrati	ion Parameters	92
	5.11.1	Rte_CData	92
	5.11.2	Rte_Prm	93
5.12	Client-Se	erver Communication	94
	5.12.1	Rte_Call	94
	5.12.2	Rte_Result	95
5.13	Indirect /	API	96
	5.13.1	Rte_Ports	96
	5.13.2	Rte_NPorts	97
	5.13.3	Rte_Port	98
5.14	RTE Life	ecycle API	99
	5.14.1	Rte_Start	99
	5.14.2	Rte Stop	99



	5.14.3	Rte_InitMemory	100
5.15	SchM Lif	fecycle API	101
	5.15.1	SchM_Init	101
	5.15.2	SchM_Deinit	101
	5.15.3	SchM_GetVersionInfo	102
5.16	VFB Tra	ce Hooks	103
	5.16.1	Rte_[<client>_]<api>Hook_<cts>_<ap>_Start</ap></cts></api></client>	103
	5.16.2	Rte_[<client>_]<api>Hook_<cts>_<ap>_Return</ap></cts></api></client>	104
	5.16.3	SchM_[<client>_]<api>Hook_<bsw>_<ap>_Start</ap></bsw></api></client>	105
	5.16.4	SchM_[<client>_]<api>Hook_<bsw>_<ap>_Return</ap></bsw></api></client>	106
	5.16.5	Rte_[<client>_]ComHook_<signalname>_SigTx</signalname></client>	107
	5.16.6	Rte_[<client>_]ComHook_<signalname>_SigIv</signalname></client>	108
	5.16.7	Rte_[<client>_]ComHook_<signalname>_SigGroupIv</signalname></client>	109
	5.16.8	Rte_[<client>_]ComHook_<signalname>_SigRx</signalname></client>	110
	5.16.9	Rte_[<client>_]ComHook<event>_<signalname></signalname></event></client>	111
	5.16.10	Rte_[<client>_]Task_Activate</client>	112
	5.16.11	Rte_[<client>_]Task_Dispatch</client>	112
	5.16.12	Rte_[<client>_]Task_SetEvent</client>	113
	5.16.13	Rte_[<client>_]Task_WaitEvent</client>	113
	5.16.14	Rte_[<client>_]Task_WaitEventRet</client>	114
	5.16.15	Rte_[<client>_]Runnable_<cts>_<re>_Start</re></cts></client>	114
	5.16.16	Rte_[<client>_]Runnable_<cts>_<re>_Return</re></cts></client>	115
5.17	RTE Inte	erfaces to BSW	116
	5.17.1	Interface to COM / LDCOM	116
	5.17.2	Interface to OS	117
	5.17.3	Interface to NVM	118
	5.17.4	Interface to XCP	118
	5.17.5	Interface to SCHM	119
	5.17.6	Interface to DET	119
	•	ion	
6.1	-	ration Variants	
6.2		nfiguration	
6.3	-	Protection and Multicore Configuration	
6.4		ory Mapping	
6.5		nerator Settings	
6.6		ment and Calibration	
6.7	•	tion Mode Configuration	
6.8		cing Configuration	
6.9		e Area Implementation	
6 10	Periodic	Trigger Implementation	133

6

Technical Reference MICROSAR RTE



	6.11	Resource Calculation	135
7	Gloss	sary and Abbreviations	136
	7.1	Glossary	136
	7.2	Abbreviations	136
8	Addit	tional Copyrights	138
9 Contact		act	120



Illustrations

Figure 2-1	AUTOSAR architecture	21
Figure 2-2	Interfaces to adjacent modules of the RTE	
Figure 4-1	RTE Include Structure	45
Figure 4-2	SWC Include Structure	46
Figure 4-3	BSW Include Structure	
Figure 4-4	Trusted RTE Partitioning example	
Figure 4-5	Non-trusted RTE Partitioning example	55
Figure 6-1	Mapping of Runnables to Tasks	
Figure 6-2	Assignment of a Task to an OS Application	122
Figure 6-3	OS Application Configuration	
Figure 6-4	Mapping of Per-Instance Memory to NV Memory Blocks	124
Figure 6-5	RTE Generator Settings	125
Figure 6-6	Measurement and Calibration Generation Parameters	126
Figure 6-7	SWC Calibration Support Parameters	128
Figure 6-8	CalibrationBufferSize Parameter	129
Figure 6-9	A2L Include Structure	129
Figure 6-10	Optimization Mode Configuration	130
Figure 6-11	VFB Tracing Configuration	131
Figure 6-12	Exclusive Area Implementation Configuration	132
Figure 6-13	Periodic Trigger Implementation Configuration	
Figure 6-14	HTML Report	
Figure 6-15	Configuration of platform settings	135
Tables		
Table 1-1	History of the document	6
Table 1-2	Reference documents	7
Table 1-1	Component history	19
Table 3-1	Supported AUTOSAR standard conform features	
Table 3-2	Not supported AUTOSAR standard conform features	
Table 3-3	Features provided beyond the AUTOSAR standard	
Table 3-4	Service IDs	
Table 3-5	Errors reported to DET	35
Table 4-1	Content of Delivery	
Table 4-2	DVCfgCmd Command Line Options	37
Table 4-3	RTE Generator Command Line Options	
Table 4-4	Generated Files of RTE Generation Phase	40
Table 4-5	Generated Files of RTE Contract Phase	41
Table 4-6	Generated Files of RTE Template Code Generation	43
Table 4-7	Generated Files of VFB Trace Hook Code Generation	
Table 4-8	Compiler abstraction and memory mapping	
Table 4-9	Compiler abstraction and memory mapping for non-cacheable variable	s.49
Table 7-1	Glossary	
Table 7-2	Abbreviations	
Table 8-1	Free and Open Source Software Licenses	138



1 Component History

The component history gives an overview over the important milestones that are supported in the different versions of the component.

Component Version	New Features
2.3	 Complex hierarchical data types like arrays of records Optimization: Depending on the configuration the Rte_Read API is generated as macro if possible
2.4	 String data type (Encoding ISO-8859-1) SWC local calibration parameters (Rte_CData) Optimization: Depending on the configuration the Rte_Write API is generated as macro if possible Generation of unmapped client runnables enabled Asynchronous C/S communication (Rte_Result)
2.5	 Support of AUTOSAR 3.0 Revision 0001 Access to calibration element prototypes of calibration components (Rte_Calprm) Access to Per-Instance Memory (Rte_Pim) SWC implementation template generation (command line option ¬g i) and Contract Phase generation (command line option ¬g c) for a complete ECU
2.6	 Intra-ECU timeout handling for synchronous C/S communication Parallel access of synchronous and asynchronous server calls to an operation of one server port Generation of an ASAM MCD 2MC / ASAP2 compatible A2L file fragment for calibration parameters and Per-Instance Memory
2.7	 Multiple instantiation of software components Compatibility mode Object code software components
2.8	 Indirect APIs (Rte_Ports, Rte_NPorts and Rte_Port) Port API Option 'EnableTakeAddress' Platform dependent resource calculation.
2.9	► Memory protection (OS with scalability class SC3/SC4)
2.10	 Mode management including mode switch triggered runnable entities and mode dependent execution of runnable entities. (Rte_Switch, Rte_Mode and Rte_Feedback for mode switch acknowledge) Data element invalidation (Rte_Invalidate and Rte_IInvalidate) Data reception error triggered runnable entities for invalidated and outdated data elements Multiple cyclic triggers per runnable entity Multiple OperationInvokedEvent triggers for the same runnable entity with compatible operations Extended A2L file generation for calibration parameters and Per-



Component Version	New Features
	Instance Memory for user defined attributes (A2L-ANNOTATION)
2.11	➤ Signal Fan-In
	Unconnected provide ports
	► Generation of unreferenced data types
	► Evaluation of COM return codes
2.12	► Basic task support (automatically selection)
	Several optimizations (e.g. unneeded interrupt locks and Schedule() call removed)
	 Enhanced error reporting with help messages (-v command line option)
	 Support of acknowledgement only mode for transmission and mode switch notification
	► Usage of compiler library functions (e.g. memcpy) removed
	► Template file update mechanism also introduced for Rte_MemMap.h
	and Rte_Compiler_Cfg.h
2.13	► Unconnected require ports
	► Basic task support (manual selection)
	► Init-Runnables no longer have name restrictions
	Automatic periodic trigger generation can be disabled e.g. useful for Schedule Table support
	► HTML Report including resource usage
	Explicit selection of task role (Application / BSW Scheduler / Non Rte)
	► Runnables with CanBelnvokedConcurrently set to false no longer
	require a mapping, if they are not called concurrently.
2.14	Support composite data types where not all primitive members require
	an invalid value
0.45	Support inclusion of user header file 'Rte_UserTypes.h'
2.15	Optimized runnable scheduling to reduce latency times
	 Allow implementation template generation for service components, complex device drivers and EcuAbstraction components
	 Optimization mode (minimize RAM consumption / minimize execution
	time)
2.16	► MinimumStartInterval attribute (runnable de-bouncing)
	► Measurement support for S/R communication, Interrunnable variables
	and mode communication. Extended A2L File generation and support
	of new ASAM MCD 2MC / ASAP2 standard. Measurement with
	XcpEvents
	Com Filter (NewDiffersOld, Always)
	Invalid value accessible from applicationSupport of second array passing variant
0.47	7
2.17	Online calibration support
	Support transmission error detection
	Support of extended record data type compatibility for S/R communication with different record layout on sender and receiver side
2.18	► Enhanced implicit communication support



Component Vancion	Now Fostures
Component Version	New Features
2.19	Support pover received status
	 Support never received status Support S/R update handling (Rte_IsUpdated based on AUTOSAR
	4.0) Enhanced magazirement august (Inter Fau S/D communication)
	 Enhanced measurement support (Inter-Ecu S/R communication) Selective file generation (only if file content is modified)
	Support for Non-Trusted BSW
2.20	► Enhanced command line interface (support for several generation
	modes in one call, optional command line parameter -m)
	Split of generated RTE into OS Application specific files
	 Byte arrays no longer need to be mapped to signal groups Allow configuration of Schedule() calls in non-preemptive tasks
	► Generation of MISRA justification comments
2.21	► Support of SystemSignals and SystemSignalGroups using the same
	name
2.22	Support of AUTOSAR 3 2 Revision 2002
2.22	 Support of AUTOSAR 3.2 Revision 0002 Support S/R update handling according AUTOSAR 3.2.2
	► Support N:1 S/R communication
	► Support unconnected calibration R-Ports
	► Enhanced initial value handling
3.90	► Support of AUTOSAR 4.0 Revision 0003
4.0	 Support of pointer implementation data types
	Support of 'On Transition' triggered runnable entities
	Support of data type symbol attributeSupport of component type symbol attribute
	 Template generation mechanism added for Rte_UserTypes.h
4.1	► Support of Rte_MemSeg.a2l
	► Enhanced command line interface (path for A2L files selectable)
4.1.1	► Multi-Core support (S/R communication)
	► Support of Inter-Runnable Variables with composite data types
4.2	Support for arrays of dynamic data length (Rte_Send/Rte_Receive)
	Support for parallel generation for multiple component typesMulti-Core support:
	C/S communication
	► Mode communication without ModeDisablings and ModeTriggers
	► Inter-ECU S/R communication
	Support mapping of individual OperationInvoked triggers
	Support of Ny Plack SWCs
12	Support of NV Block SWCs Support of VER Trace Client Profives
4.3	 Support of VFB Trace Client Prefixes Enhanced Memory Protection support
	► Memory Protection support for Multi-Core systems
	► Inter-ECU sender/receiver communication is no longer limited to the



	l.,
Component Version	New Features
	 BSW partition Mapped client/server calls are no longer limited to the BSW partition Queued sender/receiver communication is no longer limited to the BSW partition Optimized Multi-Core support without IOCs Support of Development Error Reporting Support of registering XCP Events in the XCP module configuration
4.4	 Support for unconnected client ports for synchronous C/S communication Inter-Ecu C/S communication using SOME/IP Transformer Support for PR-Ports S/R Serialization using SOME/IP Transformer and E2E Transformer Support LdCom Improved support for 3rd Party OS interoperability especially regarding OS Counter handling
4.5	 Support Postbuild-Selectable for variant data mappings and variant COM signals Support E2E Transformer for Inter-Ecu C/S communication Support tasks mappings where multiple runnable or schedulable entities using different cycle times or activation offsets are mapped to a single Basic Task. The realization uses OS Schedule Tables Support Rte_DRead API Enhanced support for PR-Ports Support ServerArgumentImplPolicy = use ArrayBaseType Support for Mode Declaration Groups with Explicit Order
4.6	 Support of PR Mode Ports Support of PR Nv Ports Support of bit field data types (CompuMethods with category BITFIELD_TEXTTABLE) Runtime optimized copying of large data Support for SW-ADDR-METHOD on RAM blocks of NvRAM SWCs
4.7	 Support of background triggers Support of data prototype mappings Support of bit field text table mappings Support of union data types Support of UTF16 data type serialization in the SOME/IP transformer Runtime optimization in the generated RTE code by usage of optimized interrupt locking APIs of the MICROSAR OS Support of further E2E profiles for data transformation with the SOME/IP and E2E transformer Support of OS counters with tick durations smaller than 1µs
4.8	 Support of COM based Transformer ComXf Support of different strategies for writing NV data in Nv Block SWCs Support of C/S Interfaces for Nv Block SWCs SWC Template generation provides user sections for documentation of



Component Version	New Features
	runnable entities
	► Wide character support in paths
	Improved counter selection for operating systems with multiple OS applications
	 Support of optimized macro implementation for SchM_Enter and SchM_Exit
	► Enhanced OS Spinlock support
	► Enable optimizations in QM partitions

Table 1-1 Component history



2 Introduction

The MICROSAR RTE generator supports RTE and contract phase generation. Additionally, application template code can be generated for software components and for VFB trace hooks.

This document describes the MICROSAR RTE generation process, the RTE configuration with DaVinci Configurator and the RTE API.

Chapter 3 gives an introduction to the MICROSAR RTE. This brief introduction to the AUTOSAR RTE can and will not replace an in-depth study of the overall AUTOSAR methodology and in particular the AUTOSAR RTE specification, which provides detailed information on the concepts of the RTE.

In addition chapter 3 describes deviations, extensions and limitations of the MICROSAR RTE compared to the AUTOSAR standard.

The RTE generation process including the command line parameters of the MICROSAR RTE generator is described in chapter 4. This chapter also gives hints for integration of the generated RTE code into an ECU project. In addition it describes the memory mapping and compiler abstraction related to the RTE and finally, chapter 4.6 describes the memory protection support of the RTE including hints for integration with the OS.

The RTE API description in chapter 5 covers the API functionality implemented in the MICROSAR RTE.

The description of the RTE configuration in chapter 6 covers the task mapping, memory mapping and the code generation settings in DaVinci Configurator. A more detailed description of the configuration tool including the configuration of AUTOSAR software components and compositions and their integration in an ECU project can be found in the online help of the DaVinci Configurator [18].

Supported AUTOSAR Release*:		4	
Supported Configuration Variants:		pre-compile	
Vendor ID:	RTE_VENDOR_ID		30 decimal (= Vector-Informatik, according to HIS)
Module ID:	RTE_MODULE_ID		2 decimal
AR Version:	RTE_AR_RELEASE_MAJOR_VERSION RTE_AR_RELEASE_MINOR_VERSION RTE_AR_RELEASE_REVISION_VERSION		AUTOSAR Release version decimal coded
SW Version:	RTE_SW_M	MAJOR_VERSION MINOR_VERSION MATCH_VERSION	MICROSAR RTE version decimal coded

^{*} For the precise AUTOSAR Release 4.x please see the release specific documentation.



2.1 Architecture Overview

The RTE is the realization of the interfaces of the AUTOSAR Virtual Function Bus (VFB) for a particular ECU. The RTE provides both standardized communication interfaces for AUTOSAR software components realized by generated RTE APIs and it also provides a runtime environment for the component code – the runnable entities. The RTE triggers the execution of runnable entities and provides the infrastructure services that enable communication between AUTOSAR SWCs. It is acting as a broker for accessing basic software modules including the OS and communication services.

The following figure shows where the MICROSAR RTE is located in the AUTOSAR architecture.




Figure 2-1 AUTOSAR architecture

RTE functionality overview:

- Execution of runnable entities of SWCs on different trigger conditions
- Communication mechanisms between SWCs (Sender/Receiver and Client/Server)
- Mode Management
- Inter-Runnable communication and exclusive area handling

² Includes EXTADC, EEPEXT, FLSEXT, ETHSWTEXT and WDGEX ³ Functionality represented in ETHTSYN and STBM

Technical Reference MICROSAR RTE



- Per-Instance Memory and calibration parameter handling
- Multiple instantiation of SWCs
- OS task body and COM / LDCOM callback generation
- Automatic configuration of parts of the OS, NvM and COM / LDCOM dependent of the needs of the RTE
- Assignment of SWCs to different memory partitions/cores

SchM functionality overview:

- Execution of cyclic triggered schedulable entities (BSW main functions)
- Exclusive area handling for BSW modules
- OS task body generation






Figure 2-2 Interfaces to adjacent modules of the RTE

©2015, Vector Informatik GmbH Version: 4.8.0 23 / 139



3 Functional Description

3.1 Features

The features listed in the following tables cover the complete functionality specified for the RTE.

The AUTOSAR standard functionality is specified in [1], the corresponding features are listed in the tables

- ► Table 3-1 Supported AUTOSAR standard conform features
- Table 3-2 Not supported AUTOSAR standard conform features

Vector Informatik provides further RTE functionality beyond the AUTOSAR standard. The corresponding features are listed in the table

Table 3-3 Features provided beyond the AUTOSAR standard

The following features specified in [1] are supported:

Supported AUTOSAR Standard Conform Features		
Explicit S/R communication (last-is-best) [API: Rte_Read, Rte_Write]		
Explicit S/R communication (queued polling) [API: Rte_Receive, Rte_Send]		
Variable length arrays		
Explicit S/R communication (queued blocking) [API: Rte_Receive]		
Implicit S/R communication [API:Rte_IRead, Rte_IWrite, Rte_IWriteRef]		
Timeout handling (DataReceiveErrorEvent) [API: Rte_IStatus]		
Data element invalidation [API: Rte_Invalidate, Rte_IInvalidate]		
Intra-Ecu S/R communication		
Inter-Ecu S/R communication		
1:N S/R communication (including network signal Fan-Out)		
N:1 S/R communication (non-queued, pure network signal Fan-In or pure Intra-Ecu)		
C/S communication (synchronous, direct calls) [API: Rte_Call]		
C/S communication (synchronous, scheduled calls) [API: Rte_Call]		
C/S communication (asynchronous calls) [API: Rte_Call]		
C/S communication (asynchronous) [API: Rte_Result]		
Intra-Ecu C/S communication		
Inter-Ecu C/S communication using SOME/IP Transformer		
N:1 C/S communication		
Explicit exclusive areas [API: Rte_Enter, Rte_Exit]		
Implicit exclusive areas		
Explicit Inter-Runnable Variables [API: Rte_IrvRead, Rte_IrvWrite]		
Implicit Inter-Runnable Variables [API: Rte_IIrvRead, Rte_IIrvWrite]		



Supported AUTOSAR Standard Conform Features

Transmission ack. status (polling and blocking) [API: Rte Feedback]

Runnable category 1a, 1b und 2

RTE Lifecycle-API [API: Rte_Start, Rte_Stop]

Nv Block Software Components

Runnable to task mapping

Data element to signal mapping

Task body generation

VFB-Tracing

Multiple trace clients

ECU-C import / export

Automatic OS configuration according the needs of the RTE (basic and extended task support)

Automatic COM / LDCOM configuration according the needs of the RTE

Primitive data types

Composite data types

Data reception triggered runnables entities (DataReceivedEvent)

Cyclic triggered runnable entities (TimingEvent)

Data transmission triggered runnable entities (DataSendCompletionEvent)

Data reception error triggered runnables entities (DataReceiveErrorEvent)

Mode switch acknowledge triggered runnable entities (ModeSwitchedAckEvent)

Mode switch triggered runnable entities (ModeSwitchEvent)

Background triggered runnable and scheduleable entities (BackgroundEvent)

Contract phase header generation

Port access to services (Port defined argument values)

Port access to ECU-Abstraction

Compatibility mode

Per-Instance Memory [API: Rte Pim]

Multiple instantiation on ECU-level

Indirect API [API: Rte_Port, Rte_NPorts, Rte_Ports]

SWC internal calibration parameters [API: Rte CData]

Shared calibration parameters (CalprmComponentType) [API: Rte Prm]

Mode machine handling [API: Rte Mode/Rte Switch]

Mode switch ack. status (polling and blocking) [API: Rte SwitchAck]

Multi-Core support (S/R communication, C/S communication, Mode communication (partially))

Memory protection

Unconnected ports

COM-Filter (NewDiffersOld, Always)

Measurement (S/R-Communication, Mode-Communication, Inter-Runnable Variables)

Runnable de-bouncing (Minimum Start Interval)



Supported AUTOSAR Standard Conform Features

Online calibration support

Never received status

S/R update handling [API: Rte IsUpdated]

Contract Phase Header generation for BSW-Scheduler

PR-Ports

Optimized S/R communication [API: Rte_DRead]

Variant Handling support (Postbuild selectable for variant data mappings and COM signals)

Data prototype mapping

Bit field texttable mapping

Table 3-1 Supported AUTOSAR standard conform features

3.1.1 Deviations

The following features specified in [1] are not supported:

Not Supported AUTOSAR Standard Conform F	Features
--	-----------------

COM-Filter (only partially supported)

Measurement (Client-Server arguments)

external Trigger (via port) [API: Rte_Trigger]

Inter-Runnable Trigger (SWC internal) [API: Rte_IrTrigger]

Tx-Ack for implicit communication [API: Rte | IFeedback]

BSW-Scheduler Mode Handling [API: SchM_Mode, SchM_Switch, SchM_SwitchAck]

external Trigger between BSW modules [API: SchM Trigger]

BSW-Scheduler Trigger [API: SchM_ActMainFunction]

BSW-Scheduler Calibration Parameter Access [API: SchM CData]

Post Build Variant Sets

Debugging and Logging Support

Variant Handling support (Pre-Compile variability, Postbuild variability for Connectors and ComponentPrototypes)

Multi-Core support (Mode communication with ModeSwitchTriggers or ModeDisablings, Rte ComSendSignalProxyImmediate, RtelocInteractionReturnValue=RTE COM)

Restarting of partitions

Re-scaling of ports / Data conversion

Pre-Build data set generation phase

Post-Build data set generation phase

Initialization of PerInstanceMemories

Asynchronous Mode Handling

MC data support

Generated BSWMD

Range checks



Not Supported AUTOSAR Standard Conform Features

RTE memory section initialisation strategies

External configuration switch strictConfigurationCheck

Table 3-2 Not supported AUTOSAR standard conform features

3.1.2 Additions/ Extensions

The following features are provided beyond the AUTOSAR standard:

Features Provided Beyond The AUTOSAR Standard Rte_InitMemory API function. See Chapter 5.14.3 for details.

Init-Runnables. See Chapter 3.6.9 for details.

VFB Trace Hooks for SchM APIs. See Chapter 5.16.3 and 5.16.4 for details.

Measurement support for mode communication. See Chapter 6.6 for details.

Measurement with XCP Events. See Chapter 6.6 for details.

S/R Serialization using SOME/IP Transformer and E2E Transformer (AR4.2.1)

C/S Serialization using SOME/IP Transformer and E2E Transformer (AR4.2.1)

LdCom Support (AR4.2.1)

ComXf Support (AR4.2.1)

Table 3-3 Features provided beyond the AUTOSAR standard

3.1.3 Limitations

There are no known limitations.



3.2 Initialization

The RTE is initialized by calling Rte_Start. Initialization is done by the ECU State Manager (EcuM).

The Basis Software Scheduler (SchM) is initialized by calling SchM_Init. Initialization is done by the ECU State Manager (EcuM).

3.3 AUTOSAR ECUs

Besides the basic software modules each AUTOSAR ECU has a single instance of the RTE to manage the application software of the ECU. The application software is modularized and assigned to one or more AUTOSAR software components (SWC).

3.4 AUTOSAR Software Components

AUTOSAR software components (SWC) are described by their ports for communication with other SWCs and their internal behavior in form of runnable entities realizing the smallest schedulable code fragments in an ECU.

The following communication paradigms are supported for port communication:

- ▶ Sender-Receiver (S/R): queued and last-is-best, implicit and explicit
- Client-Server (C/S): synchronous and asynchronous
- Mode communication
- Calibration parameter communication

S/R and C/S communication may occur Intra-ECU or between different ECUs (Inter-ECU). Mode communication and calibration parameters can only be accessed ECU internally.

In addition to Inter-SWC communication over ports, the description of the internal behavior of SWCs contains also means for Intra-SWC communication and synchronization of runnable entities.

- Inter-Runnable Variables
- Per-Instance Memory
- Exclusive Areas
- Calibration Parameters

The description of the internal behavior of SWCs finally contains all information needed for the handling of runnable entities, especially the events upon which they are triggered.

3.5 Runnable Entities

All application code is organized into runnable entities, which are triggered by the RTE depending on certain conditions. They are mapped to OS tasks and may access the communication and data consistency mechanisms provided by the SWC they belong to.



The trigger conditions for runnable entities are described below, together with the signature of the runnable entities that results from these trigger conditions. A detailed description of the signature of runnable entities may be found in section 5.3 Runnable Entities.

3.6 Triggering of Runnable Entities

AUTOSAR has introduced the concept of RTEEvents to trigger the execution of runnable entities. The following RTEEvents are supported by the MICROSAR RTE:

- TimingEvent
- DataReceivedEvent
- DataReceiveErrorEvent
- DataSendCompletedEvent
- OperationInvokedEvent
- AsynchronousServerCallReturnsEvent
- ModeSwitchEvent
- ModeSwitchedAckEvent
- InitEvent
- BackgroundEvent

The RTEEvents can lead to two different kinds of triggering:

- Activation of runnable entity
- Wakeup of waitpoint

Activation of runnable entity starts a runnable entity at its entry point while wakeup of waitpoint resumes runnable processing at a waitpoint. The second is not possible for all RTEEvents and needs an RTE API to setup this waitpoint inside the runnable entity code.

Depending on the existence of a waitpoint, runnable entities are categorized into category 1 or category 2 runnables. A runnable becomes a category 2 runnable if at least one waitpoint exists.

3.6.1 Time Triggered Runnables

AUTOSAR defines the TimingEvent for periodic triggering of runnable entities. The TimingEvent can only trigger a runnable entity at its entry point. Consequently there exists no API to set up a waitpoint for a TimingEvent. The signature of a time triggered runnable is:

void <RunnableName>([IN Rte Instance instance])



3.6.2 Data Received Triggered Runnables

AUTOSAR defines the <code>DataReceivedEvent</code> to trigger a runnable entity on data reception (queued or last-is-best) or to continue reception of queued data in a blocking <code>Rte_Receive</code> call. Both intra ECU and inter ECU communication is supported. Data reception triggered runnables have the following signature:

```
void <RunnableName>([IN Rte Instance instance])
```

3.6.3 Data Reception Error Triggered Runnables

AUTOSAR defines the DataReceiveErrorEvent to trigger a runnable entity on data reception error. A reception error could be a timeout (aliveTimeout) or an invalidated data element. The DataReceiveErrorEvent can only trigger a runnable entity at its entry point. Consequently there exists no API to set up a waitpoint for a DataReceiveErrorEvent. The signature of a data reception error triggered runnable is:

```
void <RunnableName>([IN Rte Instance instance])
```

3.6.4 Data Send Completed Triggered Runnables

AUTOSAR defines the <code>DataSendCompletedEvent</code> to signal a successful or an <code>erroneous</code> transmission of explicit S/R communication. The <code>DataSendCompletedEvent</code> can either trigger the execution of a runnable entity or continue a runnable, which waits at a waitpoint for the transmission status or the mode switch in a blocking <code>Rte_Feedback</code> call. Both intra ECU and inter ECU communication is supported. Data send completed triggered runnables have the following signature:

```
void <RunnableName>([IN Rte Instance instance])
```

3.6.5 Mode Switch Triggered Runnables

AUTOSAR defines the ModeSwitchEvent to trigger a runnable entity on either entering or exiting of a specific mode of a mode declaration group. The ModeSwitchEvent can only trigger a runnable entity at its entry point. Consequently there exists no API to set up a waitpoint for a ModeSwitchEvent. The signature of a mode switch triggered runnable is:

```
void <RunnableName>([IN Rte Instance instance])
```

3.6.6 Mode Switched Acknowledge Triggered Runnables

AUTOSAR defines the ModeSwitchedAckEvent to signal a successful mode transition. The ModeSwitchedAckEvent can either trigger the execution of a runnable entity or continue a runnable, which waits at a waitpoint for the mode transition status. Only intra ECU communication is supported. Runnables triggered by a mode switch acknowledge have the following signature:

```
void <RunnableName>([IN Rte Instance instance])
```



3.6.7 Operation Invocation Triggered Runnables

The <code>OperationInvokedEvent</code> is defined by AUTOSAR to always trigger the execution of a runnable entity. The signature of server runnables depends on the parameters defined at the C/S port. Its general appearance is as follows:

```
{void|Std ReturnType} <Runnable>([IN Rte Instance inst] {,paramlist}*)
```

The return value depends on application errors being assigned to the operation that the runnable represents. The parameter list contains input in/output and output parameters. Input parameters for primitive data type are passed by value. Input parameters for composite data types and all in/output and output parameters independent whether they are primitive or composite types are passed by reference. The string data type is handled like a composite type.

3.6.8 Asynchronous Server Call Return Triggered Runnables

The AsynchronousServerCallReturnsEvent signals the end of an asynchronous server execution and triggers either a runnable entity to collect the result by using Rte Result or resumes the waitpoint of a blocking Rte Result call.

The runnables have the following signature:

```
{void|Std_ReturnType} <Runnable>([IN Rte_Instance inst] {,paramlist}*)
```

3.6.9 Init Triggered Runnables

Initialization runnables are called once during startup and have the following signature:

```
void <RunnableName>([IN Rte Instance instance])
```

3.6.10 Background Triggered Runnables

Background triggered runnables have to be mapped to tasks with lowest priority. The runnables are called by the RTE in an endless loop – in the background – when no other runnable runs. The signature of a background triggered runnable is:

```
void <RunnableName>([IN Rte_Instance instance])
```



3.7 Exclusive Areas

An exclusive area (EA) can be used to protect either only a part of runnable code (explicit EA access) or the complete runnable code (implicit EA access). AUTOSAR specifies four implementation methods which are configured during ECU configuration of the RTE. See also Chapter 6.9.

- OS Interrupt Blocking
- All Interrupt Blocking
- OS Resource
- Cooperative Runnable Placement

All of them have to ensure that the current runnable is not preempted while executing the code inside the exclusive area.

The MICROSAR RTE analyzes the accesses to the different RTE exclusive areas and eliminates redundant ones if that is possible e.g. if runnable entities accessing the same EA they cannot preempt each other and can therefore be dropped.



Info

For SchM exclusive areas the automatic optimization is currently not supported. Optimization must be done manually by setting the implementation method to NONE.

3.7.1 OS Interrupt Blocking

When an exclusive area uses the implementation method OS INTERRUPT BLOCKING, it calling the OS **APIs** protected by SuspendOSInterrupts() ResumeOSInterrupts(). The OS does not allow the invocation of event and resource handling functions while interrupts are suspended. This precludes calls to any RTE API that is based upon an explicitly modeled waitpoint (blocking Rte Receive, Rte Feedback, Rte SwitchAck or Rte Result API) as well as synchronous server calls (which sometimes use waitpoints that are not explicitly modeled or other rescheduling points). Additionally, all APIs that might trigger a runnable entity on the same ECU or cause a blocking queue access to be released are forbidden, as well as exclusive areas implemented as OS Resource.

3.7.2 All Interrupt Blocking

When an exclusive area uses the implementation method ALL INTERRUPT BLOCKING, it **APIs** protected bν calling the OS SuspendAllInterrupts() ResumeAllInterrupts(). The OS does not allow the invocation of event and resource handling functions while interrupts are suspended. This precludes calls to any RTE API that is based upon an explicitly modeled waitpoint (blocking Rte Receive, Rte Feedback, Rte SwitchAck or Rte Result API) as well as synchronous server calls (which sometimes use waitpoints that are not explicitly modeled or other rescheduling points). Additionally, all APIs that might trigger a runnable entity on the same ECU or cause a blocking gueue access to be released are forbidden, as well as exclusive areas implemented as OS Resource.



3.7.3 OS Resource

An exclusive area using implementation method <code>OS_RESOURCE</code> is protected by OS resources entered and released via <code>GetResource()</code> / <code>ReleaseResource()</code> calls, which raise the task priority so that no other task using the same resource may run. The OS does not allow the invocation of <code>WaitEvent()</code> while an OS resource is occupied. This again precludes calls to any RTE API that is based upon an explicitly modeled waitpoint and synchronous server calls.

3.7.4 Cooperative Runnable Placement

For exclusive areas with implementation method <code>COOPERATIVE_RUNNABLE_PLACEMENT</code>, the RTE generator only applies a check whether any of the tasks accessing the exclusive area are able to preempt any other task of that group. This again precludes calls to any RTE API that is based upon an explicitly modeled waitpoint and synchronous server calls.



3.8 Error Handling

3.8.1 Development Error Reporting

By default, development errors are reported to the DET using the service $\texttt{Det}_{\tt ReportError}$ () as specified in [17], if development error reporting is enabled in the RteGeneration parameters (i.e. by setting the parameters DevErrorDetect and / or DevErrorDetectUninit).

If another module is used for development error reporting, the function prototype for reporting the error can be configured by the integrator, but must have the same signature as the service <code>Det ReportError()</code>. The reported RTE ID is 2.

The reported service IDs identify the services which are described in chapter 5. The following table presents the service IDs and the related services:

Service ID	Service
0x00	SchM Init
0x01	SchM_Deinit
0x03	SchM_Enter
0x04	SchM_Exit
0x13	Rte_Send
0x14	Rte_Write
0x15	Rte_Switch
0x16	Rte_Invalidate
0x17	Rte_Feedback
0x18	Rte_SwitchAck
0x19	Rte_Read
0x1A	Rte_DRead
0x1B	Rte_Receive
0x1C	Rte_Call
0x1D	Rte_Result
0x1F	Rte_CData
0x20	Rte_Prm
0x28	Rte_IrvRead
0x29	Rte_IrvWrite
0x2A	Rte_Enter
0x2B	Rte_Exit
0x2C	Rte_Mode
0x30	Rte_IsUpdated
0x70	Rte_Start
0x71	Rte_Stop
0x90	Rte_COMCbkTAck_ <sn></sn>
0x91	Rte_COMCbkTErr_ <sn></sn>
0x92	Rte_COMCbkInv_ <sn></sn>



Service ID	Service
0x93	Rte COMCbkRxTOut <sn></sn>
0x94	Rte_COMCbkTxTOut_ <sn></sn>
0x95	Rte_COMCbk_ <sg></sg>
0x96	Rte_COMCbkTAck_ <sg></sg>
0x97	Rte_COMCbkTErr_ <sg></sg>
0x98	Rte_COMCbkInv_ <sg></sg>
0x99	Rte_COMCbkRxTOut_ <sg></sg>
0x9A	Rte_COMCbkTxTOut_ <sg></sg>
0x9F	Rte_COMCbk_ <sn></sn>
0xF0	Rte_Task
0xF1	Rte_IncDisableFlags
0xF2	Rte_DecDisableFlags

Table 3-4 Service IDs

The errors reported to DET are described in the following table:

Error Code	Description
RTE_E_DET_ILLEGAL_NESTED_EX CLUSIVE_AREA	The same exclusive area was called nested or exclusive areas were not exited in the reverse order they were entered
RTE_E_DET_UNINIT	Rte/SchM is not initialized
RTE_E_DET_MODEARGUMENT	Rte_Switch was called with an invalid mode parameter
RTE_E_DET_TRIGGERDISABLECOU NTER	Counter of mode disabling triggers is in an invalid state
RTE_E_DET_TRANSITIONSTATE	Mode machine is in an invalid state
RTE_E_DET_MULTICORE_STARTUP	Initialization of the master core before all slave cores were initialized
RTE_E_DET_ILLEGAL_SIGNAL_ID	RTE callback was called for a signal that is not active in the current variant.

Table 3-5 Errors reported to DET

The error RTE_E_DET_UNINIT will only be reported if the parameter DevErrorDetectUninit is enabled. The reporting of all other errors can be enabled by setting the parameter DevErrorDetect.



4 RTE Generation and Integration

This chapter gives necessary information about the content of the delivery, the RTE generation process including a description about the different RTE generation modes and finally information how to integrate the MICROSAR RTE into an application environment of an ECU.

4.1 Scope of Delivery

The delivery of the RTE contains no static RTE code files. The RTE module is completely generated by the MICROSAR RTE Generator. After the installation, the delivery has the following content:

Files	Description
DVCfgRteGen.exe (including several DLLs and XML files)	Command line MICROSAR RTE generator
MicrosarRteGen.exe	MICROSAR RTE File generator
Rte.jar	DaVinci Configurator 5 adaptation modules
Settings_Rte.xml	
Rte_Bswmd.arxml	BSWMD file for MICROSAR RTE
TechnicalReference_Asr_Rte.pdf	This documentation
ReleaseNotes_MICROSAR_RTE.htm	Release Notes

Table 4-1 Content of Delivery



Info

The RTE Configuration Tool DaVinci Developer is not part of MICROSAR RTE / BSW installation package. It has to be installed separately.



4.2 RTE Generation

The MICROSAR RTE generator can be called either from the command line application ${\tt DVCfgCmd.exe}$ or directly from within the DaVinci Configurator.

4.2.1 Command Line Options

Option		Description							
project <file></file>	-p <file></file>	Specifies the absolute path to the DPA project file.							
generate	-g	Generate the given project specified in <file>.</file>							
moduleToGenerate	-m <module></module>	Specifies the module definition references, which should be generated by the -g switch. Separate multiple modules by a ','. E.g. /MICROSAR/Rte, /MICROSAR/Nm							
genArg=" <module>: <</module>	params>"	Passes the specified parameters <pre></pre>							
help	-h	Displays the general help information of DVCfgCmd.exe							

Table 4-2 DVCfgCmd Command Line Options

4.2.2 RTE Generator Command Line Options

Option	Description								
-m <obj></obj>	Selects the DaVinci model object, where <obj> is either</obj>								
	<pre><ecuprojectname> or <componenttypename>.</componenttypename></ecuprojectname></pre>								
	Note: If -g i or -g c are selected, which accepts both,								
	<pre><componenttypename> or <ecuprojectname> and the</ecuprojectname></componenttypename></pre>								
	configuration contains such objects with the same name, the component type object takes preference over the ECU project.								
	When the workspace contains only a single ECUProject or a single ComponentType, the -m parameter can be omitted.								
	With the $-m$ parameter also multiple component types can be selected, delimited with semicolons.								
-g [r c i h]	Selects generation of the RTE with the following sub options:								
	Selects RTE generation for the ECU project specified via option – m <ecuprojectname>. This is the default option. Therefore $-g$ is equal to $-g$ r.</ecuprojectname>								



С	Selects RTE contract phase header generation for a single
	component type or BSW module if -m

<ComponentTypeName/BswModuleName> or for multiple
component types and BSW modules if -m

<ComponentType1Name/BswModule1Name>;

<ComponentType2Name/BswModule2Name> or for all nonservice component types and BSW modules of an ECU project if -m <ECUProjectName>.

Selects implementation template generation for a single component type if -m <ComponentTypeName> or for multiple component types if -m

<ComponentType1Name>; <ComponentType2Name> or for all
non- service component types of an ECU project if -m
<ECUProjectName>.

The optional -f <file> parameter specifies the file name to use for the implementation template file. If the -f <file> parameter is not given, or -m contains an ECU project name, the filename defaults to <ComponentTypeName>.c.

Already existing implementation files are updated and a backup is created.

h Selects VFB trace hook template generation for the ECU project specified via option -m <ECUProjectName>.

The optional -f <file> parameter specifies the file name to use for the VFB trace hook template file. If the -f <file> parameter is not given, the filename defaults to

VFBTraceHook <ECUProjectName>.c.

Already existing implementation files are updated and a backup is created.

-o <path>

-o r=<path>

-o c=<path>

-o i=<path>

-o h=<path>

-o s=<path>

-o a=<path>

-f <file>

This parameter can be used more than one time to generate several modes in one step.

Output path for the generated files.

If more than one generation mode is active, a special path can be specified for each generation mode by assigning the path to the character that is used as sub option for the -g parameter.

Furthermore the path for the application header files in the RTE generation mode can be selected via option –o s=<path>. By default they are generated into the subdirectory "Components".

The path for A2L files can be specified with the option –o a=<path>. These files are generated into the RTE directory by default.

Note: The <path> configured with -o parameter overwrites the path which is specified in the dpa project file.

Optional parameter to specify the output file name for options -g i and -g h.

Note: For option -g i the output file name can only be specified if -m specifies a component type. The output file name cannot be specified



	when -m specifies multiple component types.
-v	Enables verbose mode which includes help information for error, warning and info messages.
-h	Displays the general help information.

Table 4-3 RTE Generator Command Line Options

4.2.3 Generation Path

The RTE output files are generated into the path which is either specified within the dpa project file or which is specified in the $-\circ$ command line option. If several generation modes are activated in parallel, for each phase a special path can be specified with the $-\circ$ command line option.

In RTE generation phase (command line option -g or -g r), the component type specific application header files are generated into the subdirectory Components. This subdirectory can be changed in the RTE generation phase with the option -o "s=<path>". In addition the directory for the A2L files, which are generated into the RTE directory by default, can be specified with the option -o "a=<path>".

4.3 MICROSAR RTE generation modes

The sections give an overview of the files generated by the MICROSAR RTE generator in the different RTE generation modes and some examples how the command line call looks like.

4.3.1 RTE Generation Phase

The following files are generated by the RTE generation: (Option -q or -q r)

File	Description
Rte_ <componenttype>.h</componenttype>	Application header file, which has to be included into the SWC code. This header file is the only file to be included in the component code. It is generated to the Components subdirectory by default.
Rte_ <componenttype>_Type.h</componenttype>	Application type header file. This header file contains SWC specific type definitions. It is generated to the Components subdirectory by default.
SchM_ <bswmodule>.h</bswmodule>	Module interlink header file, which has to be included into the BSW module code.
SchM_ <bswmodule>_Type.h</bswmodule>	Module interlink types header file. This header file contains BSW module specific type definitions.
<componenttype>_MemMap.h</componenttype>	Template contains SWC specific part of the memory mapping. It is generated to the Components subdirectory by default.
Rte.c	Generated RTE
Rte_ <osapplication>.c</osapplication>	OsApplication specific part of the generated RTE (only generated when OsApplications are configured)
Rte_PBCfg.c	The RTE post build data set configuration file contains the data structures for the postbuild RTE initialization.
Rte.h	RTE internal declarations



Rte_Main.h	Header file for RTE lifecycle API
Rte_Cfg.h	Configuration file for the RTE
Rte_Cbk.h	Contains prototypes for COM callbacks
Rte_Hook.h	Contains relevant information for VFB tracing
Rte_Type.h	Contains the application defined data type definitions and RTE internal data types
Rte_DataHandleType.h	The RTE data handle types header file contains the data handle type declarations required for the component data structures.
Rte_PBCfg.h	The RTE post build data set configuration header contains the declarations for the data structures that are used for the postbuild RTE initialization.
Rte_UserTypes.h	Template which is generated if either user defined data types are required for Per-Instance memory or if a data type is used by the RTE but generation is skipped with the typeEmitter attribute.
Rte_MemMap.h	Template contains RTE specific part of the memory mapping
Rte_Compiler_Cfg.h	Template contains RTE specific part of the compiler abstraction
usrostyp.h	Template which is only generated if memory protection support is enabled. In that case this file is included by the MICROSAR OS.
Rte.oil	OS configuration for the RTE
Rte_Needs.ecuc.arxml	Contains the RTE requirements on BSW module configuration for Os, Com and NvM.
Rte.a2l	A2L file containing CHARACTERISTIC and MEASUREMENT objects for the generated RTE
Rte_MemSeg.a2l	A2L file containing MEMORY_SEGMENT objects for the generated RTE
Rte_rules.mak, Rte_defs.mak, Rte_check.mak, Rte_cfg.mak	Make files according to the AUTOSAR make environment proposal are generated into the ${\tt mak}$ subdirectory.
Rte.html	Contains information about RAM / CONST consumption of the generated RTE as well as a listing of all triggers and their OS events and alarms.

Table 4-4 Generated Files of RTE Generation Phase

Example:

DVCfgCmd -p "InteriorLight.dpa" -m /MICROSAR/Rte -g



4.3.2 RTE Contract Phase Generation

The following files are generated by the RTE contract phase generation: (Option -q c)

File	Description
Rte_ <componenttype>.h</componenttype>	Application header file, which must be included into the SWC code. This header file is the only file to be included in the component code.
Rte_ <componenttype>_Type.h</componenttype>	Application type header file. This header file contains SWC specific type definitions.
<componenttype>_MemMap.h</componenttype>	Template contains SWC specific part of the memory mapping.
Rte.h	RTE internal declarations
Rte_Type.h	Contains the application defined data type definitions and RTE internal data types
Rte_DataHandleType.h	The RTE data handle types header file contains the data handle type declarations required for the component data structures.
Rte_UserTypes.h	Template which is generated if either user defined data types are required for Per-Instance memory or if a data type is used by the RTE but generation is skipped with the typeEmitter attribute.
Rte_MemMap.h	Template contains RTE specific part of the memory mapping
Rte_Compiler_Cfg.h	Template contains RTE specific part of the compiler abstraction
SchM_ <bswmodule>.h</bswmodule>	Module interlink header file, which has to be included into the BSW module code.
SchM_ <bswmodule>_Type.h</bswmodule>	Module interlink types header file. This header file contains BSW module specific type definitions.

Table 4-5 Generated Files of RTE Contract Phase

Example:

```
DVCfgCmd -p "InteriorLight.dpa"
    -m /MICROSAR/Rte
    -g
    --genArg="Rte: -g c -m SenderComponent"
```

The generated header files are located in a component type specific subdirectory. The application header file must be included in each source file of a SWC implementation, where the RTE API for that specific SWC type is used.

The application header file created in the RTE contract phase can be used to compile object code components, which can be linked to an RTE generated in the RTE generation phase. The application header files are generated in RTE compatibility mode.



Caution

During the RTE generation phase an optimized header file is generated. This optimized header file should be used when compiling the source code SWCs during the ECU build process.

Technical Reference MICROSAR RTE



The usage of object code SWCs, which are compiled with the application header files of the contract phase, require an "Implementation Code Type" for SWCs set to "object code" in order to tell the RTE generator in the RTE generation phase NOT to create optimized RTE API accesses but compatible ones.



4.3.3 Template Code Generation for Application Software Components

The following file is generated by the implementation template generation: (Option -q i)

File	Description
<filename>.c</filename>	An implementation template is generated if the $\neg g$ i option is selected. The $\neg f$ option specifies the name of the generated c file. If no name is selected the default name $<$ ComponentTypeName $>$.c is used.

Table 4-6 Generated Files of RTE Template Code Generation

Example:

```
DVCfgCmd -p "InteriorLight.dpa"
    -m /MICROSAR/Rte
    -g
    --genArg="Rte: -g i -m SenderComponent -f Component1.c"
```

The generated template files contain all empty bodies of the runnable entities for the selected component type. It also contains the include directive for the application header file. In addition, the available RTE API calls are included in comments.



Caution

When the destination file of the SWC template code generation is already available, code that is placed within the user code sections marked by "DO NOT CHANGE"-comments is transferred unchanged to the updated template file.

Additionally, a numbered backup of the original file is made before the new file is written.

The preservation of runnable code is done by checking for the runnable symbol. This implies that after a change of the name of a runnable the runnable implementation is preserved, while a change of the symbol results in a new empty function for the runnable.

Code that was removed during an update is kept in the "removed code" section at the bottom of the implementation file and in the numbered backups.

The template update is particularly useful when e.g. access to some interfaces has been added or removed from a runnable, because then the information of available APIs is updated by the generation process without destroying the implementation.

©2015, Vector Informatik GmbH Version: 4.8.0 43 / 139



4.3.4 VFB Trace Hook Template Code Generation

The following file is generated by the VFB trace hook template generation: (Option -q h)

File	Description
<filename>.c</filename>	An implementation template of the VFB trace hooks is generated if the $-g$ h option is selected. The $-f$ option specifies the name of the generated c file. If no name is selected the default name VFBTraceHook_< ECUProjectName >.c is used.

Table 4-7 Generated Files of VFB Trace Hook Code Generation

Example:

```
DVCfgCmd -p "InteriorLight.dpa"
    -m /MICROSAR/Rte
    -g
    --genArg="Rte: -g h -f VFBTraceHook myEcu.c"
```



Caution

When the destination file of the VFB trace hook template generation is already available, code that is placed within the user code sections marked by "DO NOT CHANGE" comments is transferred unchanged to the updated template file.

Additionally, a numbered backup of the original file is made before the new file is written.

The preservation of trace hook code is done by checking for the trace hook name. When the name of a hook changes, e.g. because the name of a data element changed, then the code of the previous trace hook is removed.

Code that was removed during an update is kept in the "removed code" section at the bottom of the implementation file and in the numbered backups.

The template update is particularly useful when some trace hooks have been added or removed due to changed interfaces or OS usage.



4.4 Include Structure

4.4.1 RTE Include Structure




Figure 4-1 RTE Include Structure



4.4.2 SWC Include Structure

The following figure shows the include structure of a SWC with respect to the RTE dependency. All other header files which might be included by the SWC are not shown.




Figure 4-2 SWC Include Structure



4.4.3 BSW Include Structure

The following figure shows the include structure of a BSW module with respect to the SchM dependency. All other header files which might be included by the BSW module are not shown.




Figure 4-3 BSW Include Structure



4.5 Compiler Abstraction and Memory Mapping

The objects (e.g. variables, functions, constants) are declared by compiler independent definitions – the compiler abstraction definitions. Each compiler abstraction definition is assigned to a memory section.

The following two tables contain the memory section names and the compiler abstraction definitions defined for the RTE and illustrate their assignment among each other.

					,															
Compiler Abstraction Definitions																וט				
Memory Mapping	RTE_VAR_ZERO_INIT	<swc>_VAR_ZERO_INIT</swc>	RTE_VAR_INIT	<swc>_VAR_INIT</swc>	RTE_VAR_NOINIT	<swc>_VAR_NOINIT</swc>	RTE_VAR_ <pim></pim>	RTE_ <nvramblock></nvramblock>	RTE_VAR_ <cal></cal>	RTE_CONST	<swc>_CONST</swc>	RTE_CONST_ <cal></cal>	RTE_CODE	<swc>_CODE</swc>	RTE_APPL_CODE	RTE_ <swc>_APPL_CODE</swc>	<swc>_APPL_VAR</swc>	RTE_ <swc>_APPL_DATA</swc>	RTE_APPL_VAR	RTE_APPL_DATA
Sections	삗	Swc	TE_	Swc	TE_	Swc	TE_	TE_	STE_	TE_	Swc	STE_	ZTE_	Swc	ZTE_	TE_	TE_	TE_	ZE L	STE_
RTE_START_SEC_VAR_ZERO_INIT_8BIT RTE_STOP_SEC_VAR_ZERO_INIT_8BIT	-	V	_	V		V					V			V			_			
RTE_START_SEC_VAR_ZERO_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_ZERO_INIT_UNSPECIFIED	•																			
RTE_START_SEC_VAR_ <osappl>_ZERO_INIT_UNSPECIFIED¹ RTE_STOP_SEC_VAR_<osappl>_ZERO_INIT_UNSPECIFIED¹</osappl></osappl>	ŀ																			
<swc>_START_SEC_VAR_ZERO_INIT_UNSPECIFIED <swc>_STOP_SEC_VAR_ZERO_INIT_UNSPECIFIED</swc></swc>																				
RTE_START_SEC_VAR_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_INIT_UNSPECIFIED			-																	
RTE_START_SEC_VAR_ <osappl>_INIT_UNSPECIFIED¹ RTE_STOP_SEC_VAR_<osappl>_INIT_UNSPECIFIED¹</osappl></osappl>			-																	
<swc>_START_SEC_VAR_INIT_UNSPECIFIED <swc>_STOP_SEC_VAR_INIT_UNSPECIFIED</swc></swc>				-																
RTE_START_SEC_VAR_NOINIT_UNSPECIFIED RTE_STOP_SEC_VAR_NOINIT_UNSPECIFIED					-															
RTE_START_SEC_VAR_ <osappl>_NOINIT_UNSPECIFIED¹ RTE_STOP_SEC_VAR_<osappl>_NOINIT_UNSPECIFIED¹</osappl></osappl>					-															
<swc>_START_SEC_VAR_NOINIT_UNSPECIFIED <swc>_STOP_SEC_VAR_NOINIT_UNSPECIFIED</swc></swc>						-														
RTE_START_SEC_VAR_ <pim>_UNSPECIFIED RTE_STOP_SEC_VAR_<pim>_UNSPECIFIED</pim></pim>							-													
RTE_START_SEC_ <nvramblock> RTE_STOP_SEC_<nvramblock></nvramblock></nvramblock>								•												
RTE_START_SEC_VAR_ <cal>_UNSPECIFIED RTE_STOP_SEC_VAR_<cal>_UNSPECIFIED</cal></cal>									•											
RTE_START_SEC_CONST_UNSPECIFIED RTE_STOP_SEC_CONST_UNSPECIFIED										•										
<swc>_START_SEC_CONST_UNSPECIFIED <swc>_STOP_SEC_CONST_UNSPECIFIED</swc></swc>											•									

¹ This memory mapping sections are only used if memory protection support is enabled

_



RTE_START_SEC_CONST_ <cal>_UNSPECIFIED RTE_STOP_SEC_CONST_<cal>_UNSPECIFIED</cal></cal>					ı	-					
RTE_START_SEC_CODE RTE_STOP_SEC_CODE							-				
<swc>_START_SEC_CODE <swc>_STOP_SEC_CODE</swc></swc>								-			
RTE_START_SEC_APPL_CODE RTE_STOP_SEC_APPL_CODE											

Table 4-8 Compiler abstraction and memory mapping

Compiler Abstraction Definitions Memory Mapping Sections	ΙШ	RTE_VAR_INIT_NOCACHE	RTE_VAR_NOINIT_NOCACHE
RTE_START_SEC_VAR_NOCACHE_ZERO_INIT_8BIT RTE_STOP_SEC_VAR_NOCACHE_ZERO_INIT_8BIT	-		
RTE_START_SEC_VAR_NOCACHE_ZERO_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_NOCACHE_ZERO_INIT_UNSPECIFIED	-		
RTE_START_SEC_VAR_ <osappl>_NOCACHE_ZERO_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_<osappl>_NOCACHE_ZERO_INIT_UNSPECIFIED</osappl></osappl>	-		
RTE_START_SEC_VAR_NOCACHE_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_NOCACHE_INIT_UNSPECIFIED			
RTE_START_SEC_VAR_ <osappl>_NOCACHE_INIT_UNSPECIFIED RTE_STOP_SEC_VAR_<osappl>_NOCACHE_INIT_UNSPECIFIED</osappl></osappl>		•	
RTE_START_SEC_VAR_NOCACHE_NOINIT_UNSPECIFIED RTE_STOP_SEC_VAR_NOCACHE_NOINIT_UNSPECIFIED			
RTE_START_SEC_VAR_ <osappl>_NOCACHE_NOINIT_UNSPECIFIED RTE_STOP_SEC_VAR_<osappl>_NOCACHE_NOINIT_UNSPECIFIED</osappl></osappl>			-

Table 4-9 Compiler abstraction and memory mapping for non-cacheable variables

The memory mapping sections and compiler abstraction defines specified in Table 4-9 are only used for variables which are shared between different cores on multicore systems. These variables must be linked into non-cacheable memory.

The RTE specific parts of <code>Compiler_Cfg.h</code> and <code>MemMap.h</code> depend on the configuration of the RTE. Therefore the MICROSAR RTE generates templates for the following files:

- Rte_Compiler_Cfg.h
- Rte_MemMap.h

They can be included into the common files and should be adjusted by the integrator like the common files too.



4.5.1 Memory Sections for Calibration Parameters and Per-Instance Memory

The variable part of the memory abstraction defines for calibration parameters <Cal> and Per-Instance Memory <Pim> depends on the configuration. The following table shows the attributes, which have to be defined in DaVinci Developer in order to assign a calibration parameter or a Per-Instance Memory to one of the configured groups. The groups represented by the enumeration values of the attributes can be configured in the attribute definition dialog in DaVinci Developer without any naming restrictions. Only the name of the attribute itself is predefined as described in the table below.

Object Type	Attribute Name	Attribute Type
Calibration Parameter	PAR_GROUP_CAL	Enumeration
Calibration Element Prototype	PAR_GROUP_EL	Enumeration
Per-Instance Memory	PAR_GROUP_PIM	Enumeration
NvBlockDataPrototype	PAR_GROUP_NVRAM	Enumeration

Details of configuration and usage of User-defined attributes can be found in the DaVinci Online Help [19].

Example for Calibration Parameters:

If the attribute PAR_GROUP_CAL contains e.g. the enumeration values CalGroupA and CalGroupB and calibration parameters are assigned to those groups, the RTE generator will create the following memory mapping defines:

```
RTE_START_SEC_CONST_CalGroupA_UNSPECIFIED
RTE_STOP_SEC_CONST_CalGroupA_UNSPECIFIED
RTE_START_SEC_CONST_CalGroupB_UNSPECIFIED
RTE_STOP_SEC_CONST_CalGroupB_UNSPECIFIED
```

In addition the following memory mapping defines are generated, if the calibration method Initialized RAM is enabled (see also Chapter 6.6):

```
RTE_START_SEC_VAR_CalGroupA_UNSPECIFIED
RTE_STOP_SEC_VAR_CalGroupA_UNSPECIFIED
RTE_START_SEC_VAR_CalGroupB_UNSPECIFIED
RTE_STOP_SEC_VAR_CalGroupB_UNSPECIFIED
```



Example for Per-Instance Memory:

If the attribute PAR_GROUP_PIM contains e.g. the enumeration values PimGroupA and PimGroupB and Per-Instance Memory is assigned to those group, the RTE generator will create the following memory mapping defines:

```
RTE_START_SEC_VAR_PimGroupA_UNSPECIFIED
RTE_STOP_SEC_VAR_PimGroupA_UNSPECIFIED
RTE_START_SEC_VAR_PimGroupB_UNSPECIFIED
RTE_STOP_SEC_VAR_PimGroupB_UNSPECIFIED
```

4.5.2 Memory Sections for Software Components

The MICROSAR RTE generator generates specific memory mapping defines for each SWC type which allows to locate SWC specific code, constants and variables in different memory segments.

The variable part $\langle SWC \rangle$ is the camel case software component type name. The RTE implementation template code generator (command line option -g i) uses the SWC specific sections to locate the runnable entities in the appropriate memory section.

The SWC type specific parts of MemMap.h depend on the configuration. The MICROSAR RTE generator creates a template for each SWC according the following naming rule:

<Swc> MemMap.h



4.5.3 Compiler Abstraction Symbols for Software Components and RTE

The RTE generator uses SWC specific defines for the compiler abstraction.

The following define is used in RTE generated SW-C implementation templates in the runnable entity function definitions.

```
<Swc> CODE
```

In addition, the following compiler abstraction defines are available for the SWC developer. They can be used to declare SWC specific function code, constants and variables.

```
<Swc>_CODE
<Swc>_CONST
<Swc>_VAR_NOINIT
<Swc>_VAR_INIT
<Swc>_VAR_ZERO_INIT
```

If the user code contains variable definitions, which are passed to the RTE API by reference in order to be modified by the RTE (e.g. buffers for reading data elements) the RTE uses the following define to specify the distance to the buffer.

```
RTE_APPL_VAR (RTE specific)
```

If the user code contains variable or constant definitions, which are passed to the RTE API as pure input parameter (e.g. buffers for sending data elements) the RTE uses the following define to specify the distance to the variable or constant.

```
RTE_<SWC>_APPL_DATA (SWC specific)
RTE_APPL_DATA (RTE specific)
```

All these SWC and RTE specific defines for the compiler abstraction might be adapted by the integrator. The configured distances have to fit with the distances of the buffers and the code of the application.



Caution

The template files <Swc>_MemMap.h, Rte_MemMap.h and Rte_Compiler_Cfg.h have to be adapted by the integrator depending on the used compiler and hardware platform especially if memory protection is enabled.

When the files are already available during RTE generation, the code that is placed within the user code sections marked by "DO NOT CHANGE"-comments is transferred unchanged to the updated template files. The behavior is the same as for template generation of other files like SWC template generation.



4.6 Memory Protection Support

The MICROSAR RTE supports memory protection as an extension to the AUTOSAR RTE specification. Therefore the memory protection support of the Operating System provides the base functionality. The support is currently limited to the Vector MICROSAR OS because the RTE requires read access to the data from all partitions what is not required by AUTOSAR. Moreover when trusted functions are used, the RTE uses wrapper functions that are only generated by MICROSAR OS.

4.6.1 Partitioning of SWCs

The partitioning of SWCs to memory areas can be done DaVinci CFG. The partitioning is based on assignment of tasks to OS applications, which is part of the OS configuration process.

There exists the restriction that all Runnable Entities of a single SWC have to be assigned to the same OS application. This restriction and the assignment of tasks to OS applications indirectly assign SWCs to OS applications. This is the basis for grouping SWCs to different memory partitions. Additional information about memory protection configuration can be found in Chapter 6.3.

4.6.2 OS Applications

The operating system supports different scalability classes (SC). Only in SC3 and SC4 the memory protection mechanism is available. Therefore the configuration of the required scalability class is the first step to enable memory partitioning. The second step is the assignment of SWCs to partitions (OS applications) which is done by assigning tasks to OS applications as described above.

The OS supports two types of OS applications:

- Non-Trusted
- Trusted

Non-Trusted OS applications run with enabled memory protection, trusted OS applications with disabled memory protection.

Both types are supported by the MICROSAR RTE and can be selected in the OS application configuration dialog or directly in the OS configuration tool.



Caution

If no assignment of tasks to OS applications exist memory protection is disabled.



4.6.3 Partitioning Architecture

When memory protection is used, one or more SWCs can be assigned to an OS application but it is not allowed to split up a SWC between two or more OS applications. That means that all runnables of a SWC have to be assigned to tasks, which belong to the same OS application. It is the responsibility of the RTE to transfer the data of S/R and the arguments of C/S port interfaces over the protection boundaries.



Caution

Client-Server invocations implemented as direct function calls should be used inside one OS application only.

The MICROSAR RTE itself and the BSW can either run in a trusted OS application or in a non-trusted OS application. Both architectures are described below.

4.6.3.1 Trusted RTE and BSW




Figure 4-4 Trusted RTE Partitioning example

This architecture overview assumes that the RTE and the BSW modules that are used by the RTE run in one or more trusted OS applications. Application software components (SWC) above the RTE can either be trusted or non-trusted. When this architecture is used,



the RTE uses trusted functions so that non-trusted SWCs can access the BSW and SWCs in other OS applications. In this architecture, Rte_Start() has to be called from a trusted task and the Com module needs to run in trusted context, too. The RTE will use the same OS application as the BSW Scheduler tasks.

An architecture where the BSW modules and the RTE are assigned to a non-trusted OS application is described in the next chapter.

4.6.3.2 Non-Trusted RTE and BSW




Figure 4-5 Non-trusted RTE Partitioning example

This architecture overview assumes that the BSW modules below the RTE, as well as the RTE itself run in a single non-trusted OS application. The SWCs above the RTE can either be assigned to the same non-trusted OS application as the BSW or they can be assigned to one or more other non-trusted or trusted OS applications. Every OS application has its own buffers which are only written by runnables that run in the same OS application. The RTE does not use trusted functions in this architecture. Therefore it is possible to create a system where all SWCs and the BSW are assigned to non-trusted OS applications and all runnables/tasks always run with enabled memory protection.



The non-trusted RTE architecture is automatically chosen when the RTE configuration fulfills the following criterions:

- ▶ The tasks that contain the BSW modules are known by the RTE. This can be achieved by configuring them as BSW Scheduler tasks (See chapter 6.2).
- All BSW Scheduler tasks are assigned to the same non-trusted OS application (further referred to as BSW OS Application). It is assumed that this is also the OS application that initializes the RTE by calling Rte_Start. The application tasks can either be assigned to the BSW OS Application or to other non-trusted or trusted OS applications.
- ▶ All SWCs with mode provide ports are assigned to the BSW OS Application.
- ▶ All SWCs that contain runnables with mode disabling dependencies or mode triggers are assigned to the BSW OS Application.
- ► There are no direct client/server calls across OS applications

No special limitations apply to SWCs that are assigned to the same OS application as the BSW. Moreover, the following RTE features can also be used by SWCs in other OS applications:

- direct or buffered inter-runnable variables
- per-instance memories
- SWC local calibration parameters
- access to calibration software components
- queued and nonqueued intra-ECU sender/receiver communication (when there is only a single sender partition)
- ▶ inter-ECU sender/receiver communication (see also chapter 4.8.1)
- direct client/server calls to runnables within the same OS application
- mapped client/server calls to runnables in the same and different OS applications (see also chapter 4.8.2)
- reading modes with the Rte Mode API
- explicit and implicit exclusive areas



4.6.4 Conceptual Aspects

For intra OS application communication no additional RTE interaction is required. Special memory protection handling is required only if communication between different OS applications exists. In that case, the RTE has to provide means to transfer data over the protection boundaries. The only possibility is the usage of trusted function calls inside the generated RTE code. Those trusted function calls are expensive concerning code usage and runtime. Therefore the usage of trusted function calls should be minimized if possible.

The MICROSAR RTE generator uses trusted function calls only if necessary. In some cases the usage of trusted function calls can be avoided by assigning the RTE buffers to the appropriate OS application. The Vector MICROSAR OS only provides write access protection but doesn't support read access protection. This behavior is the basis to avoid trusted function calls, because the writing OS application can be seen as the owner of the memory buffer. Only a simple assignment of the buffer to the appropriate OS application is necessary. This also makes it possible to completely avoid trusted function calls when the "Non-trusted RTE" architecture (chapter 4.6.3.2) is chosen.

Only if the memory assignment cannot be used, the RTE needs trusted functions to cross the protection boundaries.

For that purpose, the RTE generator uses the OS application of the BSW Scheduler tasks as its own OS application, which always needs to be trusted. The trusted functions called by the RTE are assigned to that trusted OS application. In addition to the communication between SWCs of different OS applications, there also exists communication between the COM BSW module and the RTE. Especially the notifications of the COM are done in an undefined call context. The MICROSAR RTE assumes that the calls of the COM callbacks are done from the OS application that contains the BSW Scheduler tasks.



4.6.5 Memory Protection Integration Hints

4.6.5.1 Enabling of Memory Protection support

Please make sure that memory protection is enabled by assigning tasks to OS applications and by selecting scalability class SC3 or SC4 in the OS configuration.

4.6.5.2 Memory mapping in Linker Command File

If memory protection is enabled, the RTE generator creates additional OS application specific memory sections for variables: In addition, the user has to split up his Per-Instance Memory (PIM) sections to the different OS applications. These additional memory sections have to be mapped in the linker command file to the appropriate memory segments. See OS and compiler / linker manual for details.

The individual memory sections are listed in chapter 4.5.

The standard RTE memory section defines need to be mapped to the same segments as the BSW.

OS Application specific parts of the RTE implementation are generated to separate Rte_<OsApplicationName>.c files.

4.6.5.3 OS Configuration extension

In addition to the RTE extensions in the OS configuration which are done automatically by the RTE generator, the following steps have to be done by the Integrator.

All OS objects, used by BSW modules e.g. ISRs, BSW-Tasks, OS resources, alarms etc. have to be assigned to an OS application. COM callbacks have to run in the same OS application as the RTE/BSW Scheduler tasks. Dependent on the implementation of the COM Stack, the tasks or ISRs, which call the COM callbacks must therefore be assigned to the right OS application.

In the OS configuration of an SC3 or SC4 OS, the tasks must explicitly allow access by other OS applications. Due to possible calls of <code>ActivateTask</code> or <code>SetEvent</code> inside RTE implemented COM callbacks, the accessing BSW OS applications for all application tasks, which are affected by these calls need to be configured. This is automatically done when the RTE configuration contains all BSW Scheduler tasks. Otherwise, the configuration needs to be extended by the integrator.

If the RTE configuration contains not all BSW Scheduler tasks, also the OS application that sets up the tasks and alarms by calling Rte_Start needs to be configured for the task and alarm objects in the OS configuration.

This configuration extension has to be done in the OS configuration tool.



4.7 Multicore support

Similar to the mapping of SWCs to partitions with different memory access rights, the MICROSAR RTE also supports the mapping of SWCs to partitions on different cores for parallel execution.

4.7.1 Partitioning of SWCs

The mapping of SWCs to cores happens with the help of OS Applications like in the memory protection use case. The user has to assign runnables to tasks and tasks to OS Applications in order to map SWCs to partitions. The OS Applications can then be assigned to one of the cores of the ECU. SWCs can only be assigned to a single OS Application. This means that all runnables of a SWC need to be mapped to tasks within the same OS Application.

When two SWCs on different cores communicate with each other, the RTE will automatically apply data consistency mechanisms.

4.7.2 BSW in Multicore Systems

The MICROSAR RTE assumes that all BSW modules with direct RTE interaction (e.g. COM and NVM) are located in a single BSW OS Application on a single BSW core. The only exceptions are BSW modules like OS and ECUM that need to be available on all cores. For AUTOSAR4, the BSW OS Application is the OS Application that contains the tasks with the schedulable entities. The RTE assumes that all COM and NVM callbacks are called from this BSW OS Application.

All RTE Lifecycle APIs (Rte_Start(), Rte_Stop(), Rte_InitMemory(), SchM_Init(), SchM_Deinit()) have to be called on all cores.

Cyclic triggered runnables will start to run as soon as Rte_Start() is called on the BSW core.

It is recommended to use only a single BSW OS Application per core. The RTE will then configure the access rights so that Rte_Start() can be called from the core specific BSW OS application.



Caution

The RTE will start the scheduling of cyclic triggered runnable entities as soon as Rte_Start() is called on the BSW Core. Therefore, Rte_Start() on the BSW core should only be invoked when the Rte_Start() calls on all other cores finished execution. This is checked with a DET check.



4.7.3 IOC Usage

In multicore systems, the OS provides Inter OS-Application Communicator (IOC) Objects for the communication between the individual cores. However, on many systems the memory of the different cores can also be accessed without IOCs. This is the case when the RTE variables that are used for communication are mapped to non-cacheable RAM and when they can either be accessed atomically or when the accesses are protected with a spinlock. Moreover in case of memory protection, this is only possible when a variable is only written by a single partition and when the variable can be read by the other partitions.

The MICROSAR RTE Generator tries to avoid IOCs so that it can use the same variables for intra and inter partition communication. Moreover spinlocks are only used for variables that cannot be accessed atomically.

If the RTE variables cannot be mapped to globally readable, shared, non-cacheable RAM the usage of IOCs can be enforced with the EnforceIoc parameter in the RteGeneration parameters.



Caution

RTE variables that are mapped to <code>NOCACHE</code> memory sections need to be mapped to non-cacheable RAM. See also chapter 4.5.

4.8 BSW Access in Partitioned systems

When the SWCs are assigned to different OS Applications, only the SWCs that are assigned to the BSW OS Application can access the BSW directly. SWCs that are assigned to other cores or partitions do not always have the required access rights. The same is true for runnable entities that are directly called by the BSW through client/server interfaces. The RTE can transparently provide proxy code for such BSW accesses but the user needs to map the SendSignal proxy and the server runnables to tasks in which they can be executed.

4.8.1 Inter-ECU Communication

IOCs or additional global RTE variables are automatically inserted by the RTE generator when data needs to be sent from a partition without BSW to another ECU. This is required because the COM APIs cannot be called directly in this case.

Instead, the RTE provides a schedulable entitiy Rte_ComSendSignalProxyPeriodic, which periodically calls the COM APIs when a partition without BSW transmitted data.

The schedulable entity <code>Rte_ComSendSignalProxyPeriodic</code> should be mapped to the same task as <code>Com_MainFunctionTx</code> with a lower position in task so that it can update the signals before they are transmitted by COM. <code>Rte_ComSendSignalProxyPeriodic</code> will be scheduled with the same cycle time as <code>Com_MainFunctionTx</code>. For this, the RTE generator reads the period from the COM configuration.

For the reception of signals no special handling is required. The RTE will automatically forward the received data to the appropriate partition in the COM notifications.



4.8.2 Client Server communication

Also client server calls between SWCs in different partitions are possible.

In order to execute the server runnable in another partition, the server runnable needs to be mapped to a task. The RTE will then make the server arguments available in the partition of the server runnable, execute the server runnable in the context of its task and return the results to the calling partition.

Direct client server calls to servers on other cores are not possible because this would enforce that the server is executed in the context of the client core. This would lead to data consistency problems for RTE APIs that only provide buffer pointers like Rte_Pim(). The RTE cannot use IOCs for these APIs because the actual buffer update is done by the application code.

You can instruct the RTE to generate a context switch. You can decide this over the task mapping of a function trigger.

If you consider RTE calls which originate from the same partition as the server runnable, a context switch into the task of the server runnable may not be required. Here, doing a task switch would mean an additional overhead which can be avoided.

Therefore it is also possible to configure an additional server port prototype for clients which are local to the server partition. The triggers from both server ports can then trigger the same server runnable. However, only the trigger from the port that is connected to foreign partitions needs to be mapped onto a task. As a consequence, the RTE can implement calls from partition local clients as efficient direct function calls.

Please take into account, that this is only allowed when the server runnable is not invoked concurrently or marked as "can be invoked concurrently". In addition, you can use Exclusive Areas to protect the runnable against concurrent access problems.



5 API Description

The RTE API functions used inside the runnable entities are accessible by including the SWC application header file Rte <ComponentType>.h.



Info

The following API descriptions contain the direction qualifier IN, OUT and INOUT. They are intended as direction information only and shall not be used inside the application code.

For an interfaces overview please see Figure 2-2.

5.1 Data Type Definition

The MICROSAR RTE has special handling for the implementation data types, which are defined in $Std_Types.h$ and $Platform_Types.h$ (see [7] and [8] for details). The RTE generator assumes that these data types are available and therefore skips the generation of type definitions.

In addition implementation data types where the typeEmitter attribute is set to a value different to RTE or where the value is not empty the RTE generator also skips generation of the type definition. In this case the user has to adopt the generated template file Rte_UserTypes.h which should contain the type definitions for the skipt implementation data types because the RTE itself needs the type definition.

All other primitive or composite application and implementation data types are generated by the RTE generator. This includes the data types which are assigned to a SWC by a definition of an IncludedDataTypeSet.

Floating point data types with double precision may not be used for data elements with external connectivity, because the MICROSAR COM layer lacks support for 64 bit data types.

5.1.1 Invalid Value

The MICROSAR RTE provides access to the invalid value of a primitive data type. It can be accessed with the following macro:

InvalidValue_<DataType>



Caution

Because the macro does not contain the Rte_ prefix, care must be taken not to define data types conflicting with any other symbols defined by the RTE or the application code.



5.1.2 Upper and Lower Limit

The range of the primitive application data types is specified by an upper and a lower limit. These limits are accessible from the application by using the following macro if the limits are specified:

<DataType>_LowerLimit
<DataType> UpperLimit



Caution

Because the macro does not contain the <code>Rte_prefix</code>, care must be taken not to define data types conflicting with any other symbols defined by the RTE or the application code.

5.1.3 Initial Value

Like the limits also the initial value of an un-queued data element of an S/R port prototype is accessible from the application:

Rte InitValue <PortPrototype> <DataElementPrototype>



Caution

The initial value of an Inter-Ecu S/R communication might be changed by the post-build capabilities of the communication stack. Please note that the macro of the RTE still provides the original initial value defined at pre-compile time. Please don't use the macro if the initial value will be changed in the communication stack at post-build time.

5.2 API Error Status

Most of the RTE APIs provide an error status in the API return code. For easier evaluation the MICROSAR RTE provides the following status access macros:

Rte_IsInfrastructureError(status)
Rte_HasOverlayedError(status)
Rte_ApplicationError(status)

The macros can be used inside the runnable entities for evaluation of the RTE API return code. The boolean return code of the Rte_IsInfrastructure and Rte_HasOverlayedError macros indicate if either the immediate infrastructure error flag (bit 7) or the overlay error flag (bit 6) is set.

The Rte ApplicationError macro returns the application errors without overlayed errors.



5.3 Runnable Entities

Runnable entities are configured in DaVinci and must be implemented by the user. DaVinci features the generation of a template file containing the empty bodies of all runnable entities that are configured for a specific component type.

5.3.1 <RunnableEntity>

Prototype		
<pre>void <runnableentity> ([IN Rte_Instance instance])</runnableentity></pre>		
{Std_ReturnType void} <serverrunnable> ([IN Rte_Instance instance] {, IN type [*]inputparam}* {, OUT type *outputparam}*)</serverrunnable>		
Parameter		
Instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.	
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.	
[*]inputparam, *outputparam	Parameters are only present for server runnables, i.e. runnable entities triggered by an OperationInvokedEvent. Input (IN) parameters are passed by value (primitive types) or reference (composite and string types), output (OUT) parameters are always passed by reference.	
Return code		
RTE_E_OK	Server runnables return RTE_E_OK for successful operation execution if an application error is referenced by the operation prototype. Application errors are defined at the client/server port interface.	
RTE_E_ <interf>_<error></error></interf>	Server runnables may return an application error (in the range of 1 to 63) if the operation execution was not successful. Application errors are defined at the client/server port interface and are referenced by the operation prototype.	

Existence

If configured in DaVinci.

Functional Description

The user function <RunnableEntity>() is the specific implementation of a runnable entity of a software component and has to be provided by the user. It is called from the MICROSAR RTE.

The first prototype form with no return value and only the optional instance parameter is valid for the following trigger conditions:

- ► TimingEvent: Triggered on expiration of a configured timer.
- ▶ DataReceivedEvent: Triggered on reception of a data element.
- ▶ DataReceiveErrorEvent: Triggered on reception error of a data element.
- DataSendCompletionEvent: Triggered on successful transmission of a data element.
- ▶ ModeSwitchEvent: Triggered on entering or exiting of a mode of a mode declaration group.
- ▶ ModeSwitchedAckEvent: Triggered on completion of a mode switch of a mode declaration group.
- AsynchronousServerCallReturnsEvent: Triggered on finishing of an asynchronous server



call. The Rte Result () API shall be used to get the out parameters of the server call.

The first prototype form is also valid for initialization runnables (Init-Runnables):

Triggered on startup of the RTE.

The second prototype form is valid for server runnables:

▶ OperationInvokedEvent: Triggered on invocation of the operation in a C/S port interface (server runnable). A return value is only present if application errors are referenced by the implemented operation. The parameter list is directly derived from the configured operation prototype with the addition of the optional instance parameter.

The configuration of the trigger conditions can be done in the runnable entities tab of the component type configuration.

Call Context

The call context of server runnables depends on the task mapping. Server runnables mapped to a task are executed in the context of this task, unmapped server runnables are executed in the context of the task that invoked the operation. All other runnables are invoked by the RTE in the context of the task the runnables are mapped to.



Caution

The relative priority of the assigned OS tasks is responsible for the call sequence of Init-Runnables. The RTE ensures that the Init-Runnable is called before any other runnable mapped to the same task, but does not enforce that all Init-Runnables have been executed before any other runnable is called. To make sure that all Init-Runnables are executed before any other runnable is called, all Init-Runnables should be mapped to the task with the highest priority.



Caution

Init runnables are a Vector extension to the AUTOSAR standard and may not be supported by other RTE generators.



5.4 SWC Exclusive Areas

5.4.1 Rte_Enter

Prototype		
<pre>void Rte_Enter_<exclusivearea> ([IN Rte_Instance instance])</exclusivearea></pre>		
Parameter		
Instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.	
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.	
Return code		

Existence

This API exists when at least one runnable has configured explicit access (canEnterExclusiveArea) to an exclusive area of a component.

Functional Description

The function Rte_Enter_<ea>() implements explicit access to the exclusive area. The exclusive area is defined in the context of a component type and may be accessed by all runnables of that component, either implicitly or explicitly via this API.

This function is the counterpart of Rte_Exit_{ea} (). Each call to Rte_Enter_{ea} () must be matched by a call to Rte_Exit_{ea} () in the same runnable entity. One exclusive area must not be entered more than once at a time, but different exclusive areas may be nested, as long as they are left in reverse order of entering them.

For restrictions on using exclusive areas with different implementations, see section 3.6.10.

Call Context

This function can be used inside runnable entities.



5.4.2 Rte_Exit

Prototype

void Rte Exit <ExclusiveArea> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

_

Existence

This API exists when at least one runnable has configured explicit access (canEnterExclusiveArea) to an exclusive area of a component.

Functional Description

The function Rte_Exit_<ea>() implements releasing of an explicit entered exclusive area. The exclusive area is defined in the context of a component type and may be accessed by all runnables of that component, either implicitly or explicitly via this API.

This function is the counterpart of $Rte_Enter_<ea>()$. Each call to $Rte_Enter_<ea>()$ must be matched by a call to $Rte_Exit_<ea>()$ in the same runnable entity. One exclusive area must not be entered more than once at a time, but different exclusive areas may be nested, as long as they are left in reverse order of entering them.

For restrictions on using exclusive areas with different implementations, see section 3.6.10.

Call Context

This function can be used inside runnable entities.



5.5 BSW Exclusive Areas

5.5.1 SchM_Enter

Prototype		
void SchM_Enter_ <bsw>_<exclusivearea> (void)</exclusivearea></bsw>		
Parameter		
-		
Return code		
_		

Existence

This API exists when at least one schedulable entity has configured access (canEnterExclusiveArea) to an exclusive area in the internal behavior of the BSW module description.

Functional Description

The function <code>SchM_Enter_<bsw>_<ea>()</code> implements access to the exclusive area. The exclusive area is defined in the context of a BSW module and may be accessed by all schedulable entities of that module via this API.

This function is the counterpart of SchM_Exit_<bsw>_<ea>(). Each call to SchM_Enter_<bsw>_<ea>() must be matched by a call to SchM_Exit_<bsw>_<ea>() in the same schedulable entity. One exclusive area must not be entered more than once at a time, but different exclusive areas may be nested, as long as they are left in reverse order of entering them. For restrictions on using exclusive areas with different implementation methods, see section 3.6.10.

Call Context

This function can be used inside a schedulable entity in Task or Interrupt context.



5.5.2 SchM_Exit

Prototype		
void SchM_Exit_ <bsw>_<exclusivearea> (void)</exclusivearea></bsw>		
Parameter		
_		
Return code		
_		

Existence

This API exists when at least one schedulable entity has configured access (canEnterExclusiveArea) to an exclusive area in the internal behavior of the BSW module description.

Functional Description

The function $SchM_Exit_<bsw>_<ea>()$ implements releasing of the exclusive area. The exclusive area is defined in the context of a BSW module and may be accessed by all schedulable entities of that module via this API.

This function is the counterpart of <code>SchM_Enter_<bsw>_<ea>()</code> . Each call to <code>SchM_Enter_<bsw>_<ea>()</code> in the same schedulable entity. One exclusive area must not be entered more than once at a time, but different exclusive areas may be nested, as long as they are left in reverse order of entering them. For restrictions on using exclusive areas with different implementation methods, see section 3.6.10.

Call Context

This function can be used inside a schedulable entity in Task or Interrupt context.



5.6 Sender-Receiver Communication

5.6.1 Rte_Read

Prototype

Std ReturnType Rte Read <d> ([IN Rte Instance instance,] OUT <DataType> *data)

	20	100	100	0	7
a	ra	ш	E	LE	J

instance Instance handle, used to distinguish between the different

instances in case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation

attribute.

*data The output <data> is passed by reference. The <DataType> is

the type, specified at the data element prototype in the SWC

description.

Return code

RTE E OK Data read successfully.

RTE_E_UNCONNECTED Indicates that the receiver port is not connected.

RTE E INVALID An invalidated signal has been received by the RTE.

RTE_E_MAX_AGE_EXCEEDED Indicates a timeout, detected by the COM module in case of

inter ECU communication, if an aliveTimeout is specified.

RTE E NEVER RECEIVED No data received since system start.

RTE_E_SOFT_TRANSFORMER_ERROR | An error during transformation occurred which shall be notified

to the SWC but still produces valid data as output.

RTE_E_HARD_TRANSFORMER_ERROR | An error during transformation occurred which produces invalid

data as output.

Existence

This API exists, if the runnable entity of a SWC has configured direct (explicit) access in the role dataReceivePointByArgument for the data element in the DaVinci configuration and the referenced data element prototype is configured without queued communication (isQueued=false).

Functional Description

The function $Rte_Read_{p>_< d>()}$ supplies the current value of the data element. This API can be used for explicit read of S/R data with isQueued=false. After startup Rte_Read_{p} revides the initial value.

Call Context

This function can be used inside a runnable entity of an AUTOSAR software component (SWC).



5.6.2 Rte DRead

Prototype		
<pre><datatype> Rte_DRead<d> ([IN Rte_Instance instance])</d></datatype></pre>		
Instance handle, used to distinguish between the different instances in case of multiple instantiation.		
Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.		
The return value contains the current value of the data element. The <datatype> is the (primitive) type, specified at the data element prototype in the SWC description.</datatype>		

Existence

This API exists, if the runnable entity of a SWC has configured direct (explicit) access in the role dataReceivePointByValue for the data element in the DaVinci configuration and the referenced data element prototype is configured without queued communication (isQueued=false).

Functional Description

The function $Rte_DRead__<d>()$ supplies the current value of the data element. This API can be used for explicit read of S/R data with isQueued=false. After startup or if the receiver port is unconnected, $Rte_DRead_Provides$ the initial value. The API is only available for primitive data types.

Call Context

This function can be used inside a runnable entity of an AUTOSAR software component (SWC).



5.6.3 Rte_Write

Prototype	
Std_ReturnType Rte_Write <d> ([IN</d>	Rte_Instance instance,] IN <datatype> data)</datatype>
Std_ReturnType Rte_Write <d> ([IN</d>	Rte_Instance instance,] IN <datatype> *data)</datatype>
Parameter	
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
data	The input data <data> for primitive data types without string types is passed by value. The <datatype> is the type, specified at the data element prototype in the SWC description.</datatype></data>
*data	The input data <data> for string types and composite data types is passed by reference. The <datatype> is the type, specified at the data element prototype in the SWC description.</datatype></data>
Return code	
RTE_E_OK	Data passed to communication services successfully.
RTE_E_COM_STOPPED	An infrastructure communication error was detected by the RTE.
RTE_E_SOFT_TRANSFORMER_ERROR	An error during transformation occurred which shall be notified to the SWC but still produces valid data as output.
RTE_E_HARD_TRANSFORMER_ERROR	An error during transformation occurred which produces invalid data as output.

Existence

This API exists, if the runnable entity of a SWC has configured direct (explicit) access to the data element in the DaVinci configuration and the referenced data element prototype is configured without queued communication (isQueued=false).

Functional Description

The function $Rte_Write__<d>()$ can be used for explicit transmission of S/R data with isQueued=false.

Call Context

This function can be used inside a runnable entity of an AUTOSAR software component (SWC).



5.6.4 Rte Receive

Prototype

Std_ReturnType Rte_Receive__<d> ([IN Rte_Instance instance,] OUT <DataType> *data, [OUT uint16 *length])

Parameter

instance Instance handle, used to distinguish between the different

instances in case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation

attribute.

*data The output <data> is passed by reference. The <DataType> is

the type, specified at the data element prototype in the SWC

description.

*length In case of an array with variable number of elements, the

dynamic length <length> is returned.

Return code

RTE E OK Data read successfully.

RTE_E_UNCONNECTED Indicates that the receiver port is not connected.

RTE E NO DATA A non-blocking call returned no data due to an empty receive

queue. No other error occurred.

RTE_E_TIMEOUT Returned by a blocking call after the timeout has expired. No

data returned and no other error occurred. The argument buffer

is not changed.

RTE_E_LOST_DATA Indicates that some incoming data has been lost due to an

overflow of the receive queue. This is not an error of the data

returned in the out parameter.

RTE E SOFT TRANSFORMER ERROR An error during transformation occurred which shall be notified

to the SWC but still produces valid data as output.

RTE E HARD TRANSFORMER ERROR An error during transformation occurred which produces invalid

data as output.

Existence

This API exists, if the runnable entity of a SWC has configured polling or waiting access to the data element in the DaVinci configuration and the referenced data element prototype is configured with queued communication (isQueued=true).

Functional Description

The function $Rte_Receive__<d>()$ supplies the oldest value stored in the reception queue of the data element. This API can be used for explicit read of S/R data with isQueued=true.

Call Context



5.6.5 Rte Send

1 P 1 7 2	7	70	42	V/A	
Pr	W.	3.5	45	ИВ	

Std_ReturnType Rte_Send__<d> ([IN Rte_Instance instance,] IN <DataType> data)

Std_ReturnType Rte_Send__<d> ([IN Rte_Instance instance,] IN <DataType> *data, [IN uint16 length])

Parameter

instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
data	The input data <data> for primitive data types without string types is passed by value. The <datatype> is the type, specified at the data element prototype in the SWC description.</datatype></data>
*data	The input data <data> for string types and composite data types is passed by reference. The <datatype> is the type, specified at the data element prototype in the SWC description.</datatype></data>
length	In case of an array with variable number of elements, the input data <length> specifies the dynamic array length.</length>

Return code

1 Cotain oodo	
RTE_E_OK	Data passed to communication services successfully.
RTE_E_COM_STOPPED	An infrastructure communication error was detected by the RTE.
RTE_E_LIMIT	The submitted data has been discarded because the receiver queue is full. Relevant only to intra ECU communication.
RTE_E_SOFT_TRANSFORMER_ERROR	An error during transformation occurred which shall be notified to the SWC but still produces valid data as output.
RTE E HARD TRANSFORMER ERROR	An error during transformation occurred which produces invalid

Existence

This API exists, if the runnable entity of a SWC has configured access to the data element in the DaVinci configuration and the referenced data element prototype is configured with queued communication (isQueued=true).

data as output.

Functional Description

The function $Rte_Send__<d>()$ can be used for explicit transmission of S/R data with isOueued=true.

Call Context



5.6.6 Rte IRead

Prototype		
<pre><datatype> Rte_IRead_</datatype></pre>	r> <d> ([IN Rte_Instance instance])</d>	
<pre><datatype> *Rte_IRead_</datatype></pre>	<d> ([IN Rte_Instance instance])</d>	
Parameter		
Instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.	
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.	
Return code		
<datatype></datatype>	The return value contains the buffered data for primitive data types. <datatype> is the type, specified at the data element prototype in the SWC description</datatype>	
<datatype> *</datatype>	The return value contains a reference to the buffered data for string types and composite data types. <datatype> is the type, specified at the data element prototype in the SWC description</datatype>	

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) access to the data element in the DaVinci configuration.

Functional Description

The function $Rte_IRead_<r>_<q>_<d>()$ supplies the value of the data element, stored in a buffer before starting of the runnable entity. This API can be used for buffered (implicit) read of S/R data with isQueued=false. After startup Rte_IRead provides the initial value.

Call Context



5.6.7 Rte IWrite

Prototype

void Rte_IWrite_<r>__<d> ([IN Rte_Instance instance,] IN <DataType> data)
void Rte_IWrite_<r>__<d> ([IN Rte Instance instance,] IN <DataType> *data)

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

data The input data <data> for primitive data types without string types is

passed by value. The <DataType> is the type, specified at the data

element prototype in the SWC description.

*data The input data <data> for string types and composite data types is

passed by reference. The <DataType> is the type, specified at the

data element prototype in the SWC description.

Return code

_

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) access to the data element in the DaVinci configuration.

Functional Description

The function $Rte_IWrite_<r>__<d>()$ can be used for buffered transmission of S/R data with isQueued=false. Note, that the actual transmission is performed and therefore visible for other runnable entities after the runnable entity has been terminated.

Call Context

This function can be used inside the runnable <r> of an AUTOSAR software component (SWC). Usage in other runnables of the same SWC is forbidden!



Caution

When implicit write access to a data element has been configured for a runnable, the runnable has to update the data element at least once during its execution time using the Rte_IWrite API or writing to the location returned by the Rte_IWriteRef API. Otherwise, the content of the data element is undefined upon return from the runnable.



5.6.8 Rte IWriteRef

Pr	7.5	7.7	7.8.1	20
141		E 0 1	IL YA	012

<DataType> *Rte IWriteRef <r> _<d> ([IN Rte_Instance instance])

Parameter

Instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

<DataType> * The return value contains a reference to the buffered data.

<DataType> is the type, specified at the data element prototype in the

SWC description

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) access to the data element in the DaVinci configuration.

Functional Description

The function $Rte_IWriteRef_<r>__<d>()$ can be used for buffered transmission of S/R data with isQueued=false. Note, that the actual transmission is performed and therefore visible for other runnable entities after the runnable entity has been terminated.

The returned reference can be used by the runnable entity to directly update the corresponding data elements. This is especially useful for data elements of composite types.

Call Context

This function can be used inside the runnable <r> of an AUTOSAR software component (SWC). Usage in other runnables of the same SWC is forbidden!



Caution

When implicit write access to a data element has been configured for a runnable, the runnable has to update the data element at least once during its execution time using the Rte_IWrite API or writing to the location returned by the Rte_IWriteRef API. Otherwise, the content of the data element is undefined upon return from the runnable.



5.6.9 Rte IStatus

Prototype

Std ReturnType Rte_IStatus_<r>__<d> ([IN Rte_Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

RTE_E_OK Data read successfully.

RTE_E_UNCONNECTED Indicates that the receiver port is not connected.

RTE E INVALID An invalidated signal has been received by the RTE.

RTE E MAX AGE EXCEEDED Indicates a timeout, detected by the COM module in case of inter ECU

communication, if an aliveTimeout is specified.

RTE_E_NEVER_RECEIVED No data received since system start.

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) access to the data element in the DaVinci configuration and if either

- ▶ data element outdated notification (aliveTimeout > 0) or
- data element invalidation is activated for this data element or
- ▶ the attribute handleNeverReceived is configured.

Functional Description

The function $Rte_IStatus_{r>_{q}>_{d}}()$ returns the status of the data element which can be read with Rte_IRead .

Call Context



5.6.10 Rte Feedback

- 177	~7	Z 1	VIA	VA.
Pr	<u> </u>	24	M S	LΨ

Std ReturnType Rte Feedback <d> ([IN Rte Instance instance])

	ra	100	-	7.1	7

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

blocking call only).

RTE E UNCONNECTED Indicates that the sender port is not connected.

RTE_E_TIMEOUT A timeout notification was received from COM before any error

notification (Inter-ECU only).

RTE E COM STOPPED The last transmission was rejected when either Rte Send / Rte Write

API was called and the COM was stopped or an error notification from COM was received before any timeout notification (Inter-ECU only).

RTE E TRANSMIT ACK A "transmission acknowledgement" has been received.

Existence

This API exists, if the runnable entity of a SWC has configured explicit access to the data element in the DaVinci configuration of a runnable entity and in addition the transmission acknowledgement is enabled at the communication specification. Furthermore, polling or waiting acknowledgment mode has to be specified for the same data element. If a timeout is specified, timeout monitoring for waiting acknowledgment access is enabled.

Functional Description

The function $Rte_Feedback__<d>()$ can be used to read the transmission status for explicit S/R communication. It indicated the status of data, transmitted by $Rte_Write()$ and $Rte_Send()$ calls. Depending on the configuration, the API can be either blocking or non-blocking.

Call Context



5.6.11 Rte_IsUpdated

Prototype

boolean Rte_IsUpdated__<d> ([IN Rte_Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

TRUE Data element has been updated since last read.

FALSE Data element has not been updated since last read.

Existence

This API exists, if the runnable entity of a SWC has configured explicit access to the data element in the DaVinci configuration of a runnable entity and in addition the <code>EnableUpdate</code> attribute is enabled at the communication specification.

Functional Description

The function $Rte_{IsUpdated_{p>_} < d>()}$ returns if the data element has been updated since the last read or not.

Call Context



5.7 Data Element Invalidation

5.7.1 Rte_Invalidate

Prototype

Std ReturnType Rte Invalidate <d> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different

instances in case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation

attribute.

Return code

RTE_E_OK No error occurred.

RTE_E_COM_STOPPED The RTE could not perform the operation because the COM

service is currently not available (inter ECU communication

only).

Existence

This API exists, if the runnable entity of a SWC has configured explicit and non-queued access to the data element in the DaVinci configuration of a runnable entity and in addition the data element invalidation is enabled at the communication specification (CanInvalidate=true).

Functional Description

The function $Rte_Invalidate__<d>()$ can be used to set the transmission data invalid for explicit non-queued S/R communication.

Call Context



5.7.2 Rte Ilnvalidate

Prototype

void Rte_IInvalidate_<r>__<d> ([IN Rte_Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

-

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) access to the data element in the DaVinci configuration of a runnable entity and in addition the data element invalidation is enabled at the communication specification (CanInvalidate=true).

Functional Description

The function $Rte_IInvalidate_< r>__< d>() can be used to set the transmission data invalid for implicit (buffered) S/R communication.$

Call Context



5.8 Mode Management

5.8.1 Rte_Switch

Prototype

Std_ReturnType Rte_Switch__<m> ([IN Rte_Instance instance,] IN Rte ModeType <ModeDeclarationGroup> mode)

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

mode The next mode. It is of type Rte ModeType <m>, where <m> is the

name of the mode declaration group.

Return code

RTE_E_OK Mode switch trigger passed to the RTE successfully.

RTE E LIMIT The submitted mode switch has been discarded because the mode

queue is full.

Existence

This API exists, if the runnable entity of a SWC has configured access to the mode declaration group prototype in the DaVinci configuration.

Functional Description

The function $Rte_Switch__<m>()$ can be used to trigger a mode switch of the specified mode declaration group prototype.

Call Context



5.8.2 Rte Mode

of a l	I a	INV/	na
	3-4	UB / II	pe

Rte ModeType <ModeDeclarationGroup> Rte Mode__<m> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

RTE_TRANSITION_<mg> This return code is returned if the mode machine is in a mode

transition.

RTE_MODE_<mg>_<m> This value is returned if the mode machine is not in a transition.

<m> indicates the currently active mode.

Existence

This API exists, if the runnable entity of a SWC has configured access to the mode declaration group prototype in the DaVinci configuration and the enhanced Mode API is not active.

Functional Description

The function $Rte_Mode__<m>()$ provides the current mode of a mode declaration group prototype.

Call Context



5.8.3 Enhanced Rte Mode

			1	
154	of a b	If a Y	WAY	a Ya
_	100	324	337	pe

Parameter	
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
previousMode	The previous mode is returned if the mode machine is in a transition.
nextMode	The next mode is returned if the mode machine is in a transition.
Return code	
RTE_TRANSITION_ <mg></mg>	This return code is returned if the mode machine is in a mode

RTE_TRANSITION_<mg> This return code is returned if the mode machine is in a mode transition.

RTE_MODE_<mg>_<m> This return code is returned if the mode machine is not in a transition. <m> indicates the currently active mode.

Existence

This API exists, if the runnable entity of a SWC has configured access to the mode declaration group prototype in the DaVinci configuration and the enhanced Mode API is active.

Functional Description

The function $Rte_Mode__<m>()$ provides the current mode of a mode declaration group prototype. In addition it provodes the previous mode and the next mode if the mode machine is in transition.

Call Context



5.8.4 Rte SwitchAck

Prototype

Std ReturnType Rte SwitchAck <m> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

(non-blocking call only).

RTE_E_TIMEOUT No mode switch processed within the specified timeout time, when the

switch ack API was attempted (blocking call only).

RTE_E_TRANSMIT_ACK The mode switch acknowledgement has been received.

Existence

This API exists, if the runnable entity of a SWC has configured access to the mode declaration group prototype in the DaVinci configuration of a runnable entity and in addition the mode switch acknowledgement is enabled at the mode switch communication specification. Furthermore, polling or waiting acknowledgment mode has to be specified for the same mode declaration group prototype. If a timeout is specified, timeout monitoring for waiting acknowledgment access is enabled.

Functional Description

The function $Rte_SwitchAck__<m>()$ can be used to read the mode switch status of a specific mode declaration group prototype. It indicated the status of a mode switch, triggered by an Rte_Switch call. Depending on the configuration, the API can be either blocking or non-blocking.

Call Context



5.9 Inter-Runnable Variables

5.9.1 Rte_IrvRead

Prototype

<DataType> Rte IrvRead <r> <v> ([IN Rte Instance instance])

void Rte IrvRead <r> <v> ([IN Rte Instance instance,] OUT <DataType> *data)

Parameter

Instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

*data The output <data> is passed by reference for composite data types.

The <DataType> is the type of the Inter-Runnable Variable specified in

the SWC description.

Return code

<DataType> The return value contains the current content of the Inter-Runnable

Variable of primitive data types. The <DataType> is the type of the

Inter-Runnable Variable specified in the SWC description.

Existence

This API exists, if the runnable entity of a SWC has configured direct (explicit) read access to the Inter-Runnable Variable in the SWC configuration.

Functional Description

The function $Rte_IrvRead_<r>_<v>()$ supplies the current value of the Inter-Runnable Variable. This API is used to read direct (explicit) Inter-Runnable Variables. After startup $Rte_IrvRead$ provides the configured initial value.

Call Context



5.9.2 Rte IrvWrite

Prototype

void Rte_IrvWrite_<r>_<v> ([IN Rte_Instance instance,] IN <DataType> data)
void Rte IrvWrite <r> <v> ([IN Rte Instance instance,] IN <DataType> *data)

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

data The input data <data> is passed by value for primitive data types. The

<DataType> is the type of the Inter-Runnable Variable specified in the

SWC description.

*data The input data <data> for composite data types is passed by

reference. The <DataType> is the type of the Inter-Runnable Variable

specified in the SWC description.

Return code

_

Existence

This API exists, if the runnable entity of a SWC has configured direct (explicit) write access to the Inter-Runnable Variable in the SWC configuration.

Functional Description

The function Rte_IrvIWrite_<r>_<v>() can be used for updating direct (explicit) access Inter-Runnable Variables. The update is performed immediately.

Call Context



5.9.3 Rte_IrvIRead

Prototype	
<pre><datatype> Rte_IrvIRead</datatype></pre>	d_ <r>_<v> ([IN Rte_Instance instance])</v></r>
<pre><datatype> *Rte_IrvIRea</datatype></pre>	ad_ <r>_<v> ([IN Rte_Instance instance])</v></r>
Parameter	
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
Return code	
<datatype></datatype>	The return value contains the buffered content of the Inter-Runnable Variable for primitive data types. The <datatype> is the type of the Inter-Runnable Variable specified in the SWC description.</datatype>
<datatype> *</datatype>	The return value contains a reference to the buffered content of the Inter-Runnable Variable for composite data types. The <datatype> is the type of the Inter-Runnable Variable specified in the SWC description.</datatype>

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) read access to the Inter-Runnable Variable in the SWC configuration.

Functional Description

The function $Rte_IrvIRead_< r>_< v>()$ supplies the value of the Inter-Runnable Variable, stored in a buffer before the runnable entity is started. This API is used to read the buffered (implicit) Inter-Runnable Variable. After startup $Rte_IrvIRead$ provides the configured initial value.

Call Context



5.9.4 Rte IrvIWrite

Prototype

void Rte_IrvIWrite_<r>_<v> ([IN Rte_Instance instance,] IN <DataType> data)
void Rte IrvIWrite <r> <v> ([IN Rte Instance instance,] IN <DataType> *data)

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

 $\verb"supportsMultipleInstantiation" attribute.$

data The input data <data> is passed by value for primitive data types. The

<DataType> is the type of the Inter-Runnable Variable specified in the

SWC description.

*data The input data <data> is passed by reference for composite data

types. The <DataType> is the type of the Inter-Runnable Variable

specified in the SWC description.

Return code

_

Existence

This API exists, if the runnable entity of a SWC has configured buffered (implicit) write access to the Inter-Runnable Variable in the SWC configuration.

Functional Description

Call Context

This function can be used inside the runnable <r> of an AUTOSAR software component (SWC). Usage in other runnables of the same SWC is forbidden!



Caution

When buffered (implicit) write access to an Inter-Runnable Variable has been configured for a runnable, the runnable has to update the Inter-Runnable variable at least once during its execution time using the <code>Rte_IrvIWrite</code> API. Otherwise, the content of the Inter-Runnable Variable may become undefined upon return from the runnable.



5.10 Per-Instance Memory

5.10.1 Rte_Pim

Prototype		
<c-type> *Rte_Pim_<n> (</n></c-type>	[IN Rte_Instance instance])	
<pre><datatype> *Rte_Pim_<n></n></datatype></pre>	· ([IN Rte_Instance instance])	
Parameter		
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.	
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.	
Return code		
<c-type> *</c-type>	If the configured data type of the Per-Instance Memory is specified by any C type string, a reference to the PIM of the C-type is returned.	
<datatype> *</datatype>	If the configured DataType of the Per-Instance Memory is an AUTOSAR DataType, a reference to the PIM of this AUTOSAR type is returned. If the data type is known and completely described, the RTE generator knows the size of the PIM variable and is able to generate the PIM variables in a specific optimized order.	

Existence

This API exists for each specified Per-Instance Memory specified for an AUTOSAR application SWC.

Functional Description

The function $Rte_Pim_<n>()$ can be used to access Per-Instance Memory. Note: If several runnable entities have concurrent access to the same Per-Instance Memory, the user has to protect the accesses by using implicit or explicit exclusive areas.

Call Context

This function can be used inside all runnable entities of the AUTOSAR software component (SWC) specifying the Per-Instance Memory.



Caution

When the Per–Instance Memory uses no AUTOSAR data type and is also not based on a standard data type like e.g. uint8 the RTE generator cannot create the type definition for this type.

In this case the user has to provide a user header file $Rte_UserTypes.h$ which should contain the type definitions for the Per-Instance Memory allowing the RTE generator to allocate the Per-Instance memory.



5.11 Calibration Parameters

5.11.1 Rte CData

Prototype	
<pre><datatype> Rte_CData_</datatype></pre>	cp> ([IN Rte_Instance instance])
<pre><datatype> *Rte_CData_</datatype></pre>	([IN Rte_Instance instance])
Parameter	
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
Return code	
<datatype></datatype>	For primitive data types the return value contains the content of the calibration parameter. The return value is of type <datatype>, which is the type of the calibration element prototype.</datatype>
<datatype> *</datatype>	For composite data types and string types the return value contains the reference to the calibration parameter. The return value is of type <datatype>, which is the type of the calibration element prototype.</datatype>

Existence

This API exists for each calibration element prototype specified for an AUTOSAR application SWC.

Functional Description

The function Rte_CData_<cp>() can be used to access SWC local calibration parameters. Depending on the configuration the Rte_CData API returns a SWC type specific (shared) or SWC instance specific (perInstance) calibration parameter.

Call Context

This function can be used inside all runnable entities of the AUTOSAR software component (SWC) specifying the calibration parameters.



5.11.2 Rte Prm

 100	I A	MAY.	$\mathbf{n} \bullet$
 ro	1,44	LHA'A	

<DataType> Rte_Prm__<cp> ([IN Rte_Instance instance])
<DataType> *Rte_Prm__<cp> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

<DataType> For primitive data types the return value contains the content of the

calibration parameter. The return value is of type <DataType>, which

is the type of the calibration element prototype.

<DataType> * For composite data types and string types the return value contains

the reference to the calibration parameter. The return value is of type <DataType>, which is the type of the calibration element prototype.

Existence

This API exists for each calibration element prototype specified for a calibration software component.

Functional Description

The function $Rte_Prm__<cp>()$ can be used to access the instance specific calibration element prototypes of a calibration component.

Call Context

This function can be used inside all runnable entities of the AUTOSAR software component (SWC) specifying access to calibration element prototypes of calibration components via calibration ports.



5.12 Client-Server Communication

5.12.1 Rte_Call

Prototype

Parameter

instance Instance handle, used to distinguish between the different

instances in case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation

attribute.

[*]inputparam, *outputparam,

*inoutputparam,

The number and type of parameters is determined by the operation prototype. Input (IN) parameters are passed by value (primitive types) or reference (composite and string types),

output (OUT) and input-output (INOUT) parameters are always

passed by reference.

Return code

RTE_E_OK Operation executed successfully.

RTE E UNCONNECTED Indicates that the client port is not connected.

RTE_E_LIMIT The operation is invoked while a previous invocation has not yet

terminated. Relevant only for asynchronous calls.

RTE E COM STOPPED An infrastructure communication error was detected by the RTE.

Relevant only to external communication.

RTE E TIMEOUT Returned by a synchronous call after the timeout has expired

and no other error occurred. The arguments are not changed.

RTE_E_<interf>_<error> Server runnables may return an application error if the operation

execution was not successful. Application errors are defined at the client/server port interface and are references by the

operation prototype.

RTE_E_SOFT_TRANSFORMER_ERROR An error during transformation occurred which shall be notified

to the SWC but still produces valid data as output.

RTE_E_HARD_TRANSFORMER_ERROR An error during transformation occurred which produces invalid

data as output.

Existence

This API exists, if the runnable entity of a SWC has configured access to the operation prototype in the DaVinci configuration.

Functional Description

The function $Rte_Call__<o>()$ invokes the server operation <o> with the specified parameters. If Rte_Call returns with an error, the INOUT and OUT parameters are unchanged.

Call Context



5.12.2 Rte_Result

1 P J 7	767	7.0	7.8.1	
Pr	LET	T.	JIV.	95

Std_ReturnType Rte_Result__<o> ([IN Rte_Instance instance,]
{OUT type *outputparam,}*)

Parameter

instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
*outputparam	The number and type of parameters is determined by the operation prototype. The output (OUT) parameters are always passed by reference.

Return code

RTE_E_OK	Operation executed successfully.
RTE_E_UNCONNECTED	Indicates that the client port is not connected.
RTE_E_NO_DATA	The result of the asynchronous operation invocation is not available. Relevant only for non-blocking call.
RTE_E_COM_STOPPED	An infrastructure communication error was detected by the RTE. Relevant only to external communication.
RTE_E_TIMEOUT	The result of the asynchronous operation invocation is not available in the specified time. Relevant only for blocking call.
RTE_E_ <interf>_<error></error></interf>	Server runnables may return an application error if the operation execution was not successful. Application errors are defined at the client/server port interface and are references by the operation prototype.

Existence

This API exists, if the runnable entity of a SWC has configured polling or waiting access to an asynchronous invoked operation of a C/S port interface.

Functional Description

The function $Rte_Result__<o>()$ provides the result of asynchronous C/S calls. In case of a polling call, the API returns the OUT parameters if the result is already available while for asynchronous calls the API waits until the server runnable has finished the execution or a timeout occurs.

Call Context



5.13 Indirect API

5.13.1 Rte_Ports

I	ro	7.0	7A 1	
	E, U	1,01	10.74	MY =-

Rte PortHandle <i> <R/P> Rte Ports <i> <P/R> ([IN Rte Instance instance])

Parameter

instance Instance handle, used to distinguish between the different instances in

case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of

supportsMultipleInstantiation attribute.

Return code

Rte_PortHandle_<i>_<R/P> | The API returns a pointer to the first port data structure of the port

data structure array.

Existence

This API exists, if the indirect API is configured at the Component Type.

Functional Description

The function $Rte_Ports_<i>_<R/P>$ returns an array containing the port data structures of all require ports indicated by the API extension <R> or provide ports indicated by <P> of the port interface specified by <i> in order to allow indirect access of the port APIs via the port handle (e.g. iteration over all ports of the same interface).

Call Context



5.13.2 Rte_NPorts

Prototype	
uint8 Rte_NPorts_ <i>_<i< td=""><td>P/R> ([IN Rte_Instance instance])</td></i<></i>	P/R> ([IN Rte_Instance instance])
Parameter	
instance	Instance handle, used to distinguish between the different instances in case of multiple instantiation.
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
Return code	
uint8	The API returns the size of the port data structure array provided by Rte_Ports.

Existence

This API exists, if the indirect API is configured at the component type.

Functional Description

The function $Rte_NPorts_<i>_<R/P>$ returns the number of array entries (port data structures) of all require ports indicated by the API extension <R> or provide ports indicated by <P> of the port interface specified by <i>.

Call Context



5.13.3 Rte Port

Prototype

Rte PortHandle <i> <R/P> Rte_Port_ ([IN Rte_Instance instance])

Parameter

instance

Instance handle, used to distinguish between the different instances in case of multiple instantiation.

Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.

Return code

Rte PortHandle <i> <R/P> The API returns a pointer to a port data structure.

Existence

This API exists, if the indirect API is configured at the component type.

Functional Description

The function Rte Port returns the port data structure of the port specified by . It allows indirect API access via the port handle.

Call Context



5.14 RTE Lifecycle API

The lifecycle API functions are declared in the RTE lifecycle header file Rte Main.h

5.14.1 Rte Start

K O	70	741	20
ro	Tal.	NA.	U, E

Std ReturnType Rte Start (void)

Parameter

Return code

RTE_E_OK RTE initialized successfully.

RTE_E_LIMIT An internal limit has been exceeded.

Functional Description

The RTE lifecycle API function Rte_Start allocates and initializes system resources and communication resources used by the RTE.

Call Context

This function has to be called by the ECU state manager after basic software modules have been initialized especially OS and COM. It has to be called on every core that is used by the RTE. The call on the core that contains the BSW will start the triggering of all cyclic runnables. Therefore Rte_Start on the other cores has to be executed first.

5.14.2 Rte_Stop

Prototype

Std ReturnType Rte Stop (void)

Parameter

_

Return code

RTE_E_OK RTE initialized successfully.

RTE E LIMIT A resource could not be released.

Functional Description

The RTE lifecycle API function <code>Rte_Stop</code> releases system resources and communication resources used by the RTE and shutdowns the RTE. After <code>Rte_Stop</code> is called no runnable entity must be processed.

Call Context

This function has to be called by the ECU state manager on every core that is used by the RTE. The call on the core that contains the BSW will stop the triggering of the cyclic runnables.



5.14.3 Rte_InitMemory

Prototype	
void Rte_InitMemory (v	oid)
Parameter	
-	
Return code	
-	

Functional Description

The API function Rte_InitMemory is a MICROSAR RTE specific extension and should be used to initialize RTE internal state variables if the compiler does not support initialized variables.

Call Context

This function has to be called before the ECU state manager calls the initialization functions of other BSW modules especially the AUTOSAR COM module. It has to be called on all cores that are used by the RTE.



Caution

Rte_InitMemory API is a Vector extension to the AUTOSAR standard and may not be supported by other RTE generators.



5.15 SchM Lifecycle API

The lifecycle API functions are declared in the RTE lifecycle header file Rte_Main.h

5.15.1 SchM Init

Prototype	
void SchM_Init ([IN Sc	chM_ConfigType ConfigPtr])
Parameter	
ConfigPtr	Pointer to the Rte_Config_ <variantname> data structure that shall be used for the RTE initialization of the active variant in case of a postbuild selectable configuration. The parameter is omitted in case the project contains no postbuild selectable variance.</variantname>
Return code	

Functional Description

This function initializes the BSW Scheduler and resets the timers for all cyclic triggered schedulable entities (main functions). Note that all main functions calls are activated upon return from this function.

Call Context

This function has to be called by the ECU state manager from task context. The OS has to be initialized before as well as those BSW modules for which the SchM provides triggering of schedulable entities (main functions). The API has to be called on all cores that are used by the RTE.

5.15.2 SchM_Deinit

Prototype	
void SchM_Deinit (void	1)
Parameter	
-	
Return code	
-	
Functional Description	
This function finalizes the BSW Scheduler and stops the timer which triggers the main functions.	
Call Context	

This function has to be called by the ECU state manager from task context. It has to be called on all cores that are used by the RTE.



5.15.3 SchM_GetVersionInfo

Prototype

void SchM GetVersionInfo (Std VersionInfoType *versioninfo)

Parameter

versioninfo Pointer to where to store the version information of this module.

Return code

Existence

This API exists if RteSchMVersionInfoApi is enabled.

Functional Description

 ${\tt SchM_GetVersionInfo()}\ \ \textbf{returns version information, vendor ID and AUTOSAR\ module\ ID\ of\ the\ component.}$

The versions are decimal-coded.

Call Context

The function can be called on interrupt and task level.



5.16 VFB Trace Hooks

The RTE's "VFB tracing" mechanism allows to trace interactions of the AUTOSAR software components with the VFB. The choice of events resides with the user and can range from none to all. The "VFB tracing" functionality is designed to support multiple clients for each event. If one or multiple clients are specified for an event, the trace function without client prefix will be generated followed by the trace functions with client prefixes in alphabetically ascending order.

5.16.1 Rte_[<client>_]<API>Hook_<cts>_<ap>_Start

Prototype	
<pre>void Rte_[<client>_]<af)<="" params="" pre=""></af></client></pre>	PI>Hook_ <cts>_<ap>_Start ([IN const Rte_CDS_<cts>* inst,]</cts></ap></cts>
Parameter	
Rte_CDS_ <cts>* inst</cts>	The instance specific pointer of type Rte_CDS_ <cts> is used to distinguish between the different instances in case of multiple instantiation.</cts>
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
params	The parameters are the same as the parameters of the <api>. See the corresponding API description for details.</api>
Return code	
-	

Existence

This VFB trace hook exists if the global and the hook specific configuration switches are enabled.

Functional Description

This VFB trace hook is called inside the RTE APIs directly after invocation of the API. The user has to provide this hook function if it is enabled in the configuration. The placeholder <API> represents one of the following APIs:

Enter, Exit, Write, Read, Send, Receive, Invalidate, SwitchAck, Switch, Call, Result, IrvWrite, IrvRead

The <AccessPoint> is defined as follows:

- Enter, Exit: <ExclusiveArea>
- Write, Read, Send, Receive, Feedback, Invalidate: <PortPrototype>_<DataElementPrototype>
- Switch, SwitchAck: <PortPrototype> <ModeDeclarationGroupPrototype>
- Call, Result: <PortPrototype>_<OperationPrototype>
- IrvWrite, IrvRead: <InterRunnableVariable>

Call Context

This function is called inside the RTE API. The call context is the context of the API itself. Since APIs can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component (SWC).

©2015, Vector Informatik GmbH Version: 4.8.0 103 / 139



5.16.2 Rte_[<client>_]<API>Hook_<cts>_<ap>_Return

70	7	744	00
roi	N. W.	UNI	W. W.

void Rte_[<client>_]<API>Hook_<cts>_<ap>_Return ([IN const Rte_CDS_<cts> *inst,]
params)

	ra		

Rte_CDS_ <cts>* inst</cts>	The instance specific pointer of type Rte_CDS_ <cts> is used to distinguish between the different instances in case of multiple instantiation.</cts>
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.
params	The parameters are the same as the parameters of the API. See the corresponding API description for details.

Return code

_

Existence

This VFB trace hook exists if the global and the hook specific configuration switches are enabled.

Functional Description

This VFB trace hook is called inside the RTE APIs directly before leaving the API. The user has to provide this hook function if it is enabled in the configuration. The placeholder <API> represents one of the following APIs:

Enter, Exit, Write, Read, Send, Receive, Invalidate, Feedback, Switch, SwitchAck, Call, Result, IrvWrite, IrvRead

The <AccessPoint> is defined as follows:

- Enter, Exit: <ExclusiveArea>
- Write, Read, Send, Receive, Feedback, Invalidate: <PortPrototype>_<DataElementPrototype>
- Switch, SwitchAck: <PortPrototype>_<ModeDeclarationGroupPrototype>
- Call, Result: <PortPrototype>_<OperationPrototype>
- IrvWrite. IrvRead: <InterRunnableVariable>

Call Context

This function is called inside the RTE API. The call context is the context of the API itself. Since APIs can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component (SWC).



Caution

The RTE generator tries to prevent overhead by sometimes implementing the Rte_Call API as macro that does a direct runnable invocation. If VFB trace hooks are enabled for such an Rte_Call API or for the called server runnable, these optimizations are no longer possible.

Also macro optimizations for Rte_Read, Rte_DRead, Rte_Write, Rte_IrvRead and Rte_IrvWrite APIs are disabled when VFB tracing for that APIs is enabled.





Caution

The RTE does not call VFB trace hooks for the following APIs because they are intended to be implemented as macros.

- ► Implicit S/R APIs: Rte_IWrite, Rte_IWriteRef, Rte_IRead, Rte_IStatus, Rte_IInvalidate
- ▶ Implicit Inter-Runnable Variables: Rte IrvIWrite, Rte IrvIRead
- ► Per-instance Memory and calibration parameter APIs: Rte_Pim, Rte_CData, Rte_Prm
- ▶ Indirect APIs: Rte Ports, Rte Port, Rte NPorts
- ▶ RTE Life-Cycle APIs: Rte_Start, Rte_Stop

5.16.3 SchM_[<client>_]<API>Hook_<Bsw>_<ap>_Start

Prototype		
void SchM_[<client>_]<api>Hook_<bsw>_<ap>_Start (params)</ap></bsw></api></client>		
Parameter		
params	The parameters are the same as the parameters of the <api>. See the corresponding API description for details.</api>	
Return code		
-		
E 1.4.		

Existence

This VFB trace hook exists if the global and the hook specific configuration switches are enabled.

Functional Description

This VFB trace hook is called inside the RTE APIs directly after invocation of the API. The user has to provide this hook function if it is enabled in the configuration. The placeholder <API> represents one of the following APIs:

Enter, Exit

The <AccessPoint> is defined as follows:

Enter, Exit: <ExclusiveArea>

Call Context

This function is called inside the RTE API. The call context is the context of the API itself. Since APIs can be called from a BSW function, the context of the trace hooks depends on the context of the BSW function.



Caution

The SchM Hook APIs are a Vector extension to the AUTOSAR standard and may not be supported by other RTE generators.



5.16.4 SchM_[<client>_]<API>Hook_<Bsw>_<ap>_Return

Prototype		
void SchM_[<client>_]<api>Hook_<bsw>_<ap>_Return (params)</ap></bsw></api></client>		
Parameter		
params	The parameters are the same as the parameters of the <api>. See the corresponding API description for details.</api>	
Return code		

Existence

This VFB trace hook exists if the global and the hook specific configuration switches are enabled.

Functional Description

This VFB trace hook is called inside the RTE APIs directly before leaving the API. The user has to provide this hook function if it is enabled in the configuration. The placeholder <API> represents one of the following APIs:

Enter, Exit

The <AccessPoint> is defined as follows:

Enter, Exit: <ExclusiveArea>

Call Context

This function is called inside the RTE API. The call context is the context of the API itself. Since APIs can be called from a BSW function, the context of the trace hooks depends on the context of the BSW function.



Caution

The SchM Hook APIs are a Vector extension to the AUTOSAR standard and may not be supported by other RTE generators.



5.16.5 Rte_[<client>_]ComHook_<SignalName>_SigTx

Prototype		
<pre>void Rte_[<client>_]ComHook_<signalname>_SigTx (<datatype> *data)</datatype></signalname></client></pre>		
Parameter		
<datatype>* data</datatype>	Pointer to data to be transmitted via the COM API.	
	Note: <datatype> is the application specific data type of Rte_Send, Rte_Write or Rte_IWrite.</datatype>	
Return code		
-		

Existence

This VFB trace hook exists, if at least one data element prototype of a port prototype has to be transmitted over a network (Inter-Ecu) and the global and the hook specific configuration switches are enabled.

Functional Description

This hook is called just before the RTE invokes <code>Com_SendSignal</code> or <code>Com_UpdateShadowSignal</code>.

Call Context

This function is called inside the RTE APIs Rte_Send and Rte_Write. The call context is the context of the API itself. Since APIs can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component.

If buffered communication (Rte_IWrite) is used, the call context is the task of the mapped runnable.



5.16.6 Rte_[<client>_]ComHook_<SignalName>_Siglv

Prototype		
void Rte_[<client>_]ComHook_<signalname>_SigIv (void)</signalname></client>		
Parameter		
-		
Return code		
-		

Existence

This VFB trace hook exists, if at least one data element prototype of a port prototype has to be transmitted over a network (Inter-Ecu) and the global and the hook specific configuration switches are enabled. In addition the <code>canInvalidate</code> attribute at the UnqueuedSenderComSpec of the data element prototype must be enabled.

Functional Description

This hook is called just before the RTE invokes Com InvalidateSignal.

Call Context

This function is called inside the RTE APIs Rte_Invalidate. The call context is the context of the API itself. Since APIs can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component.

If buffered communication (Rte_IInvalidate) is used, the call context is the task of the mapped runnable.



5.16.7 Rte_[<client>_]ComHook_<SignalName>_SigGroupIv

Prototype	
void Rte_[<client>_]Com</client>	Hook_ <signalgroupname>_SigGroupIv (void)</signalgroupname>
Parameter	
-	
Return code	
-	

Existence

This VFB trace hook exists, if at least one data element prototype of a port prototype is composite and has to be transmitted over a network (Inter-Ecu) and the global and the hook specific configuration switches are enabled. In addition the <code>canInvalidate</code> attribute at the UnqueuedSenderComSpec of the data element prototype must be enabled.

Functional Description

This hook is called just before the RTE invokes Com InvalidateSignalGroup.

Call Context

This function is called inside the RTE APIs Rte_Invalidate. The call context is the context of the API itself. Since APIs can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component.

If buffered communication (Rte_IInvalidate) is used, the call context is the task of the mapped runnable.



5.16.8 Rte_[<client>_]ComHook_<SignalName>_SigRx

Prototype				
void Rte_[<client>_]ComHook_<signalname>_SigRx (<datatype> *data)</datatype></signalname></client>				
Parameter				
<datatype>* data</datatype>	Pointer to the data received via the COM API.			
	Note: <datatype> is the application specific data type of Rte_Receive, Rte_Read, Rte_DRead or Rte_IRead.</datatype>			
Return code				
-				

Existence

This VFB trace hook exists, if at least one data element prototype of a port prototype has to be received from a network and the global and hook specific configuration switches are enabled.

Functional Description

This VFB Trace Hook is called after the RTE invokes $Com_ReceiveSignal$ or $Com_ReceiveShadowSignal$.

Call Context

This function is called inside the RTE API Rte_Read or Rte_DRead. The call context is the context of the API itself. Since this API can only be called in runnable context, the context of the trace hooks is also the runnable entity of an AUTOSAR software component.

If buffered communication (Rte_IRead) is used, the call context is the task of the mapped runnable.

If queued communication is configured (Rte_Receive), the call of the Com API is called inside the COM callback after reception. In this case, the context of the trace hook is the context of the COM callback.

Note: This could be the task context or the interrupt context!



5.16.9 Rte_[<client>_]ComHook<Event>_<SignalName>

Prototype	
void Rte_[<client></client>	_]ComHook <event>_<signalname> (void)</signalname></event>
Parameter	
-	
Return code	
-	

Existence

This VFB trace hook is called inside the <Event> specific COM callback, directly after the invocation by COM and if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates the start of a COM callback. <Event> depends on the type of the callback.

empty string: Rte COMCbk <SignalName>

▶ TxTOut Rte_COMCbkTxTOut_<SignalName>
 ▶ RxTOut Rte_COMCbkRxTOut_<SignalName>
 ▶ TAck Rte_COMCbkTAck_<SignalName>
 ▶ TErr Rte_COMCbkTErr_<SignalName>
 ▶ Inv Rte_COMCbkInv_<SignalName>

Call Context

This function is called inside the context of the COM callback.

Note: This could be the task context or the interrupt context!



5.16.10 Rte_[<client>_]Task_Activate

Prototype

void Rte [<client>]Task Activate (TaskType task)

Parameter

task The same parameter is also used to call the OS API ActivateTask

Return code

Existence

This VFB trace hook is called by the RTE immediately before the invocation of the OS API ActivateTask and if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates the call of ActivateTask of the OS.

Call Context

This function is called inside <code>Rte_Start</code> and in the context RTE API functions which trigger the execution of a runnable entity where the runnable is mapped to a basic task. For API functions, the call context is the runnable context.

5.16.11 Rte_[<client>_]Task_Dispatch

Prototype

void Rte_[<client>_]Task_Dispatch (TaskType task)

Parameter

task The parameter indicates the task to which was started (dispatched) by the OS

Return code

_

Existence

This VFB trace hook exists for each configured RTE task and is called directly after the start if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates the call activation of a task by the OS.

Call Context

The call context is the task.



5.16.12 Rte_[<client>_]Task_SetEvent

-	100	10	7 A 1	pe
	I III a 1	1, 4,	10.1	

void Rte [<client>]Task SetEvent (TaskType task, EventMaskType event)

Parameter

task
The same parameter is also used to call the OS API SetEvent
event
The same parameter is also used to call the OS API SetEvent

Return code

_

Existence

This VFB trace hook is called by the RTE immediately before the invocation of the OS API SetEvent and if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates the call of SetEvent.

Call Context

This function is called inside RTE API functions and in COM callbacks. For API functions, the call context is the runnable context.

Note: For COM callbacks the context could be the task context or the interrupt context!

5.16.13 Rte_[<client>_]Task_WaitEvent

Prototype

void Rte [<client>] Task WaitEvent (TaskType task, EventMaskType event)

Parameter

task The same parameter is also used to call the OS API WaitEvent event The same parameter is also used to call the OS API WaitEvent

Return code

| -

Existence

This VFB trace hook is called by the RTE immediately before the invocation of the OS API WaitEvent and if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates the call of WaitEvent.

Call Context

This function is called inside RTE API functions and in generated task bodies.



5.16.14 Rte_[<client>_]Task_WaitEventRet

Prototype	
void Rte_[<clie< th=""><th>nt>_]Task_WaitEventRet (TaskType task, EventMaskType event)</th></clie<>	nt>_]Task_WaitEventRet (TaskType task, EventMaskType event)
Parameter	
task	The same parameter is also used to call the OS API WaitEvent
event	The same parameter is also used to call the OS API WaitEvent
Return code	
-	

Existence

This VFB trace hook is called by the RTE immediately after returning from the OS API WaitEvent and if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates leaving the call of WaitEvent.

Call Context

This function is called inside RTE API functions and in generated task bodies.

5.16.15 Rte_[<client>_]Runnable_<cts>_<re>_Start

Prototype				
void Rte_[<client>_]Runnable_<cts>_<re>_Start ([IN const Rte_CDS_<cts> *inst])</cts></re></cts></client>				
Parameter				
Rte_CDS_ <cts>* inst</cts>	The instance specific pointer of type Rte_CDS_ <cts> is used to distinguish between the different instances in case of multiple instantiation.</cts>			
	Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.			
Return code				
-				

Existence

This VFB trace hook is called for all mapped runnable entities if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates invocation of the runnable entity. It is called just before the call of the runnable entity and allows for example measurement of the execution time of a runnable together with the counterpart Rte_[<client>_]Runnable_<cts>_<re>_Return.

Call Context

This function is called inside RTE generated task bodies.



5.16.16 Rte_[<client>_]Runnable_<cts>_<re>_Return

Prototype			
void Rte_[<client>_]Ru</client>	nnable_ <cts>_<re>_Return ([IN const Rte_CDS_<cts> *inst])</cts></re></cts>		
Parameter			
Rte_CDS_ <cts>* inst</cts>	The instance specific pointer of type Rte_CDS_ <cts> is used to distinguish between the different instances in case of multiple instantiation.</cts>		
Note: This is an optional parameter depending on the configuration of supportsMultipleInstantiation attribute.			
Return code			
-			

Existence

This VFB trace hook is called for all mapped runnable entities if the global and the hook specific configuration switches are enabled.

Functional Description

This trace hook indicates invocation of the runnable entity. It is called just after the call of the runnable entity and allows for example measurement of the execution time of a runnable together with the counterpart Rte_[<client>_]Runnable_<cts>_<re>_Start.

Call Context

This function is called inside RTE generated task bodies.



5.17 RTE Interfaces to BSW

The RTE has standardized Interfaces to the following basic software modules

- ► COM / LDCOM
- ► NVM
- DET
- ► OS
- ► XCP
- ▶ SCHM

The actual used API's of these BSW modules depend on the configuration of the RTE.

5.17.1 Interface to COM / LDCOM

Used COM API

Com_SendSignal

Com_SendDynSignal

Com SendSignalGroup

Com UpdateShadowSignal

Com ReceiveSignal

Com ReceiveDynSignal

Com ReceiveSignalGroup

Com ReceiveShadowSignal

Com_InvalidateSignal

Com InvalidateSignalGroup

Used LDCOM API

LdCom IfTransmit

The RTE generator provides COM / LDCOM callback functions for signal notifications. The generated callbacks, which are called inside the COM layer, have to be configured in the COM / LDCOM configuration accordingly. The necessary callbacks are defined in the Rte Cbk.h header file.



Caution

The RTE generator assumes that the context of COM / LDCOM callbacks is either a task context or an interrupt context of category 2.

It is explicitly NOT allowed that the call context of a COM / LDCOM callback is an interrupt of category 1.

In order to access the COM / LDCOM API the generated RTE includes the Com.h/LdCom.h header file if necessary.

During export of the ECU configuration description the necessary COM / LDCOM callbacks are exported into the COM / LDCOM section of the ECU configuration description.



5.17.2 Interface to OS

In general, the RTE may use all available OS API functions to provide the RTE functionality to the software components. The following table contains a list of used OS APIs of the current RTE implementation.

Used OS API

SetRelAlarm

CancelAlarm

StartScheduleTableRel

NextScheduleTable

StopScheduleTable

SetEvent

GetEvent

ClearEvent

WaitEvent

GetTaskID

GetCoreID

ActivateTask

Schedule

TerminateTask

ChainTask

GetResource

ReleaseResource

GetSpinlock

ReleaseSpinlock

DisableAllInterrupts

EnableAllInterrupts

SuspendAllInterrupts

ResumeAllInterrupts

SuspendOSInterrupts

ResumeOSInterrupts

CallTrustedFunction (MICROSAR OS specific)

locWrite

locRead

locWriteGroup

IocReadGroup

locSend

locReceive

In order to access the OS API the generated RTE includes the Os.h header file.



The OS configuration needed by the RTE is stored in the file Rte_Needs.ecuc.arxml which is created during the RTE Generation Phase.

For legacy systems the OS configuration is also stored in Rte.oil. This file is an incomplete OIL file and contains only the RTE relevant configuration. It should be included in an OIL file used for the OS configuration of the whole ECU.



Caution

The generated files Rte_Needs.ecuc.arxml and Rte.oil file must not be changed!

5.17.3 Interface to NVM

The RTE generator provides NvM callback functions for synchronous copying of the mirror buffers to and from the NvM. The generated callbacks, which are called inside the $NvM_MainFunction$, have to be configured in the NvM configuration accordingly. The necessary callbacks are defined in the Rte Cbk.h header file.



Caution

The RTE generator assumes that the call context of NvM callbacks is the task which calls the NvM MainFunction.

During export of the ECU configuration description the necessary NVM callbacks are exported into the NVM section of the ECU configuration description.

5.17.4 Interface to XCP

In addition to the usage of the Com and the OS module as described by AUTOSAR, the MICROSAR RTE generator optionally can also take advantage of the MICROSAR XCP module.

This makes it possible to configure the RTE to trigger XCP Events when certain measurement points are reached.

This for example also allows the measurement of buffers for implicit sender/receiver communication when a runnable entity is terminated.

Measurement is described in detail in chapter 6.6 Measurement and Calibration.

When measurement with XCP Events is enabled, the RTE therefore includes the header xcp.h and calls the Xcp Event API to trigger the events.

Used Xcp API

Xcp Event



5.17.5 Interface to SCHM

In multicore and memory protection systems, the schedulable entity Rte_ComSendSignalProxyPeriodic is provided by the RTE and is used to access the COM from OS Applications without BSW. This schedulable entity needs to be called periodically by the SCHM.

See chapter 4.8.1 for details.

Provided Schedulable Entity

Rte_ComSendSignalProxyPeriodic

5.17.6 Interface to DET

The RTE generator reports development errors to the DET, if development error detection is enabled.

See chapter 3.8.1 for details.

Used DET API

Det ReportError



6 RTE Configuration

The RTE specific configuration in DaVinci Configurator encompasses the following parts:

- assignment of runnables to OS tasks
- assignment of OS tasks to OS applications (memory protection/multicore support)
- assignment of Per-Instance Memory to NV memory blocks
- selection of the exclusive area implementation method
- configuration of the periodic triggers
- configuration of measurement and calibration
- selection of the optimization mode
- selection of required VFB tracing callback functions
- configuration of the built-in call to the RTE generator
- platform dependent resource calculation

6.1 Configuration Variants

The RTE supports the configuration variants

- ▶ VARIANT-PRE-COMPILE
- ▶ VARIANT-POST-BUILD-SELECTABLE

The configuration classes of the RTE parameters depend on the supported configuration variants. For their definitions please see the Rte_bswmd.arxml file.

6.2 Task Configuration

Runnable Entities triggered by any kind of RTE Event e.g. TimingEvent have to be mapped to tasks. Only server runnables (triggered by an OperationInvokedEvent) that either have their CanBeInvokedConcurrently flag enabled or that are called from tasks that cannot interrupt each other do not need to be mapped. For optimization purposes they can be called directly and are then executed in the context of the calling runnable (client).

The task configuration within DaVinci Configurator also contains some attributes which are part of the OS configuration. The parameters are required to control RTE generation.



The creation of tasks is done in OS Configuration Editor in the in the DaVinci Configurator. The **Task Mapping Assistant** has to be used to assign the triggered functions (runnables and schedulable entities) to the tasks.




Figure 6-1 Mapping of Runnables to Tasks

The MICROSAR RTE supports the generation of both BASIC and EXTENDED tasks. The Task Type can either be selected or the selection is done automatically if AUTO is configured.

While extended tasks are used for tasks that need to wait for different RTE trigger conditions, basic tasks are used when all runnables of a task are triggered by one or more identical triggers.

A typical example for this might be several cyclic triggered runnables that share the same activation offset and cycle time.

Moreover another requirement for basic task usage is that the mapped runnables do not use APIs that requires a waitpoint, like a blocking Rte Feedback ().

In addition to the Task Type the number of possible task activations can be configured in the same dialog.



Caution

When RTE events that trigger a runnable are fired multiple times before the actual runnable invocation happens and when the runnable is mapped to an extended task, the runnable is invoked only once.

However, if the runnable is mapped to a basic task, the same circumstances will cause multiple task activations and runnable invocations. Therefore, for basic tasks, the task attribute Activation in the OS configuration has to be set to the maximum number of



queued task activations. If Activation is too small, additional task activations may result in runtime OS errors. To avoid the runtime error the number of possible Task Activation should be increased.

6.3 Memory Protection and Multicore Configuration

For memory protection or multicore support the tasks have to be assigned to OS applications. The following figures show the configuration of OS applications and the assignment of OS tasks. For multicore support also the Core ID has to configured for the OS application.




Figure 6-2 Assignment of a Task to an OS Application



Caution

Make sure that the operating system is configured with scalability class SC3 or SC4.

Technical Reference MICROSAR RTE






Figure 6-3 OS Application Configuration



6.4 NV Memory Mapping

Each instance of a Per-Instance Memory, which has configured **Needs memory mapping** can be mapped to an NV memory block of the NvM.

The Per-Instance Memory (PIM) is used as mirror buffer for the NV memory block. During startup, the EcuM calls $NvM_ReadAll$, which initializes the configured PIM with the value of the assigned NV memory block. During shutdown, $NvM_WriteAll$ stores the current value of the PIM buffer in the corresponding NV memory block.

The RTE configurator provides support for manual mapping of already existing NV memory blocks or automatically generation of NV memory blocks and mapping for all PIMs.

The RTE has no direct Interface to the NvM in the source code. There exists only an Interface on configuration level. The RTE configurator has to configure the following parts of the NvM configuration.

- ▶ Address of PIM representing the RAM mirror of the NV memory block.
- Optionally the address of calibration parameter for default values.
- Optionally the size of the PIM in bytes if available during configuration time.

The following figure shows the **Memory Mapping** in DaVinci Configurator where assignment of Per-Instance Memory to NV memory blocks can be configured.




Figure 6-4 Mapping of Per-Instance Memory to NV Memory Blocks



6.5 RTE Generator Settings

The following figure shows how the MICROSAR RTE Generator has to be enabled for code generation within the DaVinci Configurator.




Figure 6-5 RTE Generator Settings



6.6 Measurement and Calibration

The MICROSAR RTE generator supports the generation of an ASAM MCD-2MC compatible description of the generated RTE that can be used for measurement and calibration purposes. When measurement or calibration is enabled the RTE generator generates a file Rte.a2l that contains measurement objects for sender/receiver ports, per-instance memories and inter-runnable variables. Calibration parameters are represented as characteristic objects.




Figure 6-6 Measurement and Calibration Generation Parameters

The switch A2L Version controls the ASAM MCD-2MC standard to which the Rte.a2l file is compliant. Version 1.6.0 is recommended as it supports a symbol link attribute that can be used by the measurement and calibration tools to automatically obtain the address of a characteristic or measurement object in the compiled and linked RTE code.

What measurements and characteristics are listed in the Rte.a21 file depends on the measurement and calibration settings of the individual port interfaces, per-instance memories, inter-runnable variables and calibration parameters and if the variable can be measured in general. For example, measurement is not possible for queued communication as described in the RTE specification. When "Calibration Access" is set to "NotAccessible", an object will not be listed in the Rte.a21 file.



Within the Rte.a21 file, the measurement objects are grouped by SWCs. When inter-ECU sender/receiver communication shall be measured, the groups will also contain links to measurement objects with the name of the COM signal handle. These measurement objects have to be provided by the COM.

Furthermore, the generated Rte.a21 is only a partial A2L file. It is meant to be included in the MODULE block of a skeleton A2L file with the ASAM MCD-2MC /include command.

This makes it possible to specify additional measurement objects, for example from the COM, and IF DATA blocks directly in the surrounding A2L file.

In order to also allow the measurement of implicit buffers for inter-ECU communication, the MICROSAR RTE generator supports measurement with the help of XCP Events. This is controlled by the flag "Use XCPEvents". When XCP Events are enabled, the RTE generator triggers an XCP Event that measures the implicit buffer after a runnable with implicit inter-ECU communication is terminated and before the data is sent. "Use XCPEvents" also enables the generation of one XCP Event at the end of every task that can be used to trigger the measurement of other objects.

The RTE generator automatically adds the XCP Events to the configuration of the XCP module. The Event IDs are then automatically calculated by the XCP module.

The definitions for the Events are generated by the XCP module into the file XCP_events.a21. This file can be included in the DAQ section of the IF_DATA XCP section in the skeleton A2L file.

The MICROSAR RTE supports three different online calibration methods, which can be selected globally for the whole ECU. They differ in their kind how the APIs Rte_CData and Rte_Prm access the calibration parameter. By default the online calibration is switched off. The following configuration values can be selected:

- None
- Single Pointered
- Double Pointered
- Initialized RAM

In addition to the ECU global selection of the method the online calibration have to be activated for each component individually by setting the **Calibration Support** switch.






Figure 6-7 SWC Calibration Support Parameters

For each component with activated Calibration Support memory segments are generated into the file <code>Rte_MemSeg.a2l</code>. This file can be included in the MOD_PAR section in the skeleton A2L file. This makes it possible to specify additional memory segments in the surrounding A2L file.

If the method Initialized RAM is selected, segments for the Flash data section and the RAM data section of each calibration parameter are generated. The Flash sections are mapped to the corresponding RAM sections.

If the Single Pointered or Double Pointered method is enabled, only memory segments for the Flash data sections are listed in the <code>Rte_MemSeg.a21</code>. In addition a segment for a RAM buffer is generated, when the Single Pointered method is used and a <code>CalibrationBufferSize</code> is set. This parameter specifies the size of the RAM buffer in byte. If it is set to 0, no RAM buffer will be created.






Figure 6-8 CalibrationBufferSize Parameter

The following figure shows a possible include structure of an A2L file. In addition to the fragment A2L files that are generated by the RTE generator other parts (e.g. generated by the BSW) can be included in the skeleton A2L file.




Figure 6-9 A2L Include Structure

For more details about the creation of a complete A2L file see [20].



6.7 Optimization Mode Configuration

A general requirement to the RTE generator is production of optimized RTE code. If possible the MICROSAR RTE Generator optimizes in different optimization directions at the same time. Nevertheless, sometimes it isn't possible to do that. In that case the default optimization direction is "Minimum RAM Consumption". The user can change this behavior by manually selection of the optimization mode.

- ► Minimum RAM Consumption (MEMORY)
- ► Minimum Execution Time (RUNTIME)

The following figure shows the **Optimization Mode** Configuration in DaVinci Configurator.




Figure 6-10 Optimization Mode Configuration



6.8 VFB Tracing Configuration

The VFB Tracing feature of the MICROSAR RTE may be enabled in the DaVinci Configrator as shown in the following picture.




Figure 6-11 VFB Tracing Configuration

You may open an already generated $Rte_Hook.h$ header file from within this dialog. This header file contains the complete list of all available trace hook functions, which can be activated independently. You can select and copy the names and insert these names into the trace function list of this dialog manually or you can import a complete list from a file. If you want to enable all trace functions you can import the trace functions from an already generated $Rte_Hook.h$. The VFB Trace Client Prefix defines an additional prefix for all VFB trace functions to be generated. With this approach it is for example possible to enable additionally trace functions for debugging (Dbg) and diagnostic log and trace (Dlt) at the same time.



Info

All enabled trace functions have to be provided by the user. Section 4.3.4 describes how a template for VFB trace hooks can be generated initially or updated after configuration changes.



6.9 Exclusive Area Implementation

The implementation method for exclusive areas can be set in the DaVinci Configurator as shown in the following picture.




Figure 6-12 Exclusive Area Implementation Configuration



6.10 Periodic Trigger Implementation

The runnable activation offset and the trigger implementation for cyclic runnable entities may be set in the ECU project editor as shown in the following picture.




Figure 6-13 Periodic Trigger Implementation Configuration



Caution

Currently it is not supported to define an activation offset and a trigger implementation per trigger. The settings can only be made for the complete runnable with potential several cyclic triggers.

The activation offset specifies at what time relative to the start of the RTE the runnable / main function is triggered for the first time.

Trigger implementation can either be set to Auto or None. When it is set to the default setting Auto, the RTE generator will automatically generate and set OS alarms that will then trigger the runnables / main functions. When trigger implementation is set to None, the RTE generator only creates the tasks and events for triggering the runnables / main functions. It is then the responsibility of the user to periodically activate the basic task to which a runnable / main function is mapped or to send an event when the runnable / main function is mapped to an extended task.



This feature can also be used to trigger cyclic runnable entities / main functions with a schedule table. This allows the synchronization with FlexRay.

To ease the creation of such a schedule table, the generated report Rte.html contains a trigger listing. The listing contains the triggered runnables / main functions, their tasks and the used events and alarms.

5 Task List

Task	Туре	Schedule	Priority
T1	Extended	NON	1
T2	Basic	NON	2

Back

6 Trigger List

Trigger	Runnable	Task	OS Event	OS Alarm
TimingEvent Cyclic 2ms	Runnable1	T1	Rte_Ev_Run1_c_Runnable1	
TimingEvent Cyclic 2ms	Runnable2	T2	n/a	
TimingEvent Cyclic 5ms	RunnableCyclic	T1	Rte_Ev_Run_c_RunnableCyclic	Rte_Al_TE_c_RunnableCyclic
TimingEvent Cyclic 5ms	Runnable3	T1	Rte_Ev_Run1_c_Runnable3	

Figure 6-14 HTML Report

If the OS alarm column for a trigger is empty, the runnable / main function needs to be triggered manually. In the example above, this is the case for all runnables except for RunnableCyclic.

The row for Runnable2 does not contain an event because this runnable is mapped to a basic task.

To manually implement the cyclic triggers, one could for example create a repeating schedule table in the OS configuration with duration 10 that uses a counter with a tick time of one millisecond. An expiry point at offset 0 would then need to contain SETEVENT actions for the runnables Runnable1 and Runnable3 and an ACTIVATETASK action for Runnable2.

Moreover further expiry points with the offsets 2, 4, 6, 8 are needed to activate Runnable1 and Runnable2 and another expiry point with offset 5 is needed to activate Runnable3.



Caution

When the trigger implementation is set to none, the settings for the cycle time and the activation offset are no longer taken into account by the RTE. It is then the responsibility of the user to periodically trigger the runnables / main functions at the configured times. Moreover the user also has to make sure that this triggering does not happen before the RTE is completely started.



6.11 Resource Calculation

The RTE generator generates the file Rte.html containing the RAM and CONST usage of the generated RTE. The RTE generator makes the following assumptions.

- ▶ Size of a pointer: 2 bytes. The default value of the RTE generator can be changed with the parameter Size Of RAM Pointer in the EcuC module.
- Size of the OS dependent data type TaskType: 1 byte
- Size of the OS dependent data type EventMaskType: 1 byte
- ▶ Padding bytes in structures and arrays are considered according to the configured parameters Struct Alignment and Struct In Array Alignment in the EcuC module for NvM blocks.
- Size of a boolean data type: 1 byte (defined in PlatformTypes.h)

The pointer size and the alignment parameters can be found in the container EcuC/EcucGeneral in the Basic Editor of DaVinci Configurator.




Figure 6-15 Configuration of platform settings



7 Glossary and Abbreviations

7.1 Glossary

Term	Description
DaVinci DEV	DaVinci Developer: The SWC Configuration Editor.
DaVinci CFG	DaVinci Configurator: The BSW and RTE Configuration Editor.

Table 7-1 Glossary

The AUTOSAR Glossary [14] also describes a lot of important terms, which are used in this document.

7.2 Abbreviations

Abbreviation	Description
API	Application Programming Interface
AUTOSAR	Automotive Open System Architecture
BSW	Basis Software
Com	Communication Layer
ComXf	Com based Transformer
C/S	Client-Server
E2E	End-to-End Communication Protection
E2EXf	End-to-End Transformer
EA	Exclusive Area
ECU	Electronic Control Unit
EcuM	ECU State Manager
FOSS	Free and Open Source Software
HIS	Hersteller Initiative Software
IOC	Inter OS-Application Communicator
ISR	Interrupt Service Routine
MICROSAR	Microcontroller Open System Architecture (Vector's AUTOSAR solution)
NvM	Non-volatile Memory Manager
PIM	Per-Instance Memory
OIL	OSEK Implementation Language
OSEK	Open Systems and their corresponding Interfaces for Electronics in Automotive
RE	Runnable Entity
SE	Schedulable Entity
RTE	Runtime Environment
SchM	Schedule Manager

Technical Reference MICROSAR RTE



SOME/IP	Scalable service-oriented middleware over IP
SomelpXf	SOME/IP Transformer
S/R	Sender-Receiver
SWC	Software Component
SWS	Software Specification
VFB	Virtual Functional Bus

Table 7-2 Abbreviations



8 Additional Copyrights

The MICROSAR RTE Generator contains *Free and Open Source Software* (FOSS). The following table lists the files which contain this software, the kind and version of the FOSS, the license under which this FOSS is distributed and a reference to a license file which contains the original text of the license terms and conditions. The referenced license files can be found in the directory of the RTE Generator.

File	FOSS	License	License Reference
MicrosarRteGen.exe	Perl 5.20.2	Artistic License	License_Artistic.txt
Newtonsoft.Json.dll	Json.NET 6.0.4	MIT License	License_JamesNewton-King.txt
Rte.jar	flexjson 2.1	Apache License V2.0	License_Apache-2.0.txt

Table 8-1 Free and Open Source Software Licenses



9 Contact

Visit our website for more information on

- News
- Products
- Demo software
- Support
- Training data
- Addresses

www.vector.com